




Si Programmer™

Software Manual



for

1240i
3540i
7080i

Si2035
Si3540
Si5580
Si-100

BLUDC4-Si
BLUDC9-Si
BLUAC5-Si
SV7-Si

ST5-Si
ST10-Si
STAC6-Si
STAC6-Si-220



Contents

Getting Started.....	5
Installing the Programming Software	6
Connecting to your PC.....	7
What if my PC has no Serial Port?	7
Programming.....	8
Which Software Version do I Have?	9
Entering Your Program	9
Copying Instructions	11
Protecting Your Program with a Password	12
User Defined Units	12
Inserting and Deleting Program Steps	12
Front Panel STOP Button.....	13
Setting the Step Motor Current	13
Idle Current Reduction	14
Setting the Servo Motor Current	14
Microstepping (Step Motors Only)	14
Jogging	15
Configure Inputs Dialog.....	16
Interrupt.....	16
Quick Decel Rate	18
Limit Switches	18
What Happens When You Hit a Limit Switch?.....	18
Motion Output (BLU Servo).....	19
Motion Output (STAC6 & ST5/10)	19
Brake Output (BLU Servo, STAC6 and ST5/10).....	19
Special STAC6 and ST5/10 Dialogs.....	20
Servo Faults	22
Front Panel Error Codes.....	23
Using the Optional MMI.....	26
How to display a message on the MMI	27
How to pause until user presses ENTER	28
How to let the user make a decision (MMI branching)	29
How to ask the user for a move distance	29
How to get a speed from the user.....	30
How to get a repeat count from the user.....	30
How to create an MMI Menu	31
Making Your Move	32
MMI Prompt	32
Feed to Length	34
Feed & Set Output	36
Feed & Return.....	37
Feed to Sensor.....	38
Feed to Sensor & Return	40
Feed to Position	41
Set Abs Position.....	42
Save Abs Position	43
Seek Home	44
Wait Time	45
Wait Input	46
Hand Wheel	47
Go To.....	48
Repeat/End Repeat	49
Reset Loop or Interrupt.....	51
Set Output.....	52
If Input Go To.....	53
Call and Return	55
Change Current	56

Change Servo	57
Comment	58
Command Buttons.....	59
Download, Upload & Execute	59
Execute Panel Commands: Stop, Run, Pause, Step and Reset	59
Save, Open, Print & Quit.....	61
Encoder Feedback: 3540i with Encoder Option Board	62
Encoder Feedback: STAC6 & ST5/10	64
Servo Tuning & Motor Set Up.....	66
Alarms Dialog.....	66
Regen Dialog.....	67
The Motor/Encoder Dialog	67
Encoder and Hall Timing	67
The Tuning Dialog.....	69
The Scope.....	69
Control Loop Tuning	70
Stiffness Gain Terms	71
P: The Proportional Term	71
I: The Integral	71
Damping Gain Terms	71
D: The Derivative.....	71
Vfb: Velocity Feedback.....	72
Vff: Velocity Feedforward.....	72
Inertia Gain Term: Acceleration Feedforward	72
Filters	72
Menu Options	73
Drive...Restore Factory Defaults	73
Drive...Position Error Limit.....	73
Tools...Monitor	74
Servo Tuning Tutorial	75
Getting Ready for Tuning.....	75
1) Entering a Sample Move	76
2) Start with the KP & KD parameters	76
3) Let's Plot a Move.....	76
5) The return of KVf and KVff parameters.....	77
6) Adding in the KAff parameter.....	78
7) Finishing off with the KI parameter	79
8) Verify the Drive Current.....	79

Getting Started

Thank you for purchasing an Applied Motion Products Si™ product. We hope you will find that the performance, price and ease of programming make our products the best value for your application.

The *Si Programmer™* software is used in many Applied Motion products, including the 1240i, 3540i, 7080i, Si2035, Si3540, Si5580 and STAC6-Si step motor drives, the BLUDC4-Si, BLUDC9-Si, BLUAC5-Si and SV7-Si digital servo drives and the Si-100 indexer. This manual explains how to install the *Si Programmer™* software and how to program your Si™ product.

For information regarding your specific Si™ hardware, such as wiring and mounting, please read the hardware manual for that product. Hardware manuals are also included on the CD, at our web site or by clicking the Help button in the software.

The *Si Programmer™* features include:

- Powerful, flexible, easy to use indexer.
- Nonvolatile program storage.
- Automatic, stand alone execution of stored program.
- Connection by a simple cable to your PC for programming (cable included).
- Programmable inputs & outputs for interacting with other equipment.
- Interrupt on input, branch on end of travel limit, branch on servo fault.
- Instructions for motion, triggering, branching, loops, subroutines, time delays and more.
- User defined units such as inches, degrees, gallons, etc.
- Optional man machine interface (MMI) allows operator to enter distances, speeds, loop counts and more.
- Built-in servo configuration and tuning including a digital storage scope.

To operate your Si™ product, you must do the following:


- Install our software program on your PC.
- Connect a motor (for the Si-100, you'll need a motor and a pulse & direction drive).
- Connect any inputs or outputs that you require.
- Plug into your personal computer for programming.
- Connect & apply power.

If you have trouble getting your Si™ Indexer to meet your expectations, or if you want to suggest improvements to the product or this manual, give us a call at (800) 525-1609 or write to techsupport@applied-motion.com.

Note: This manual was prepared for Si Programmer 2.7 and the latest drive firmware. If your drive contains a previous firmware revision, then some of the features described in this manual may not be available to you. The Si Programmer software will alert you to this fact if you try to download a program that your drive cannot execute.


If your PC contains an older version of the Si Programmer™ software, please install the new version. You do NOT have to uninstall the old version first. The latest Si Programmer™ software is designed to work with every version and model Si™ drive ever produced.

1




Install Si Programmer™

2



Create Your Program

3




Download Your Program

4




Test Your Program

5



Remove Power & Disconnect

6



Apply Power: Program Autoruns

Installing the Programming Software

The *Si Programmer™* software comes on a CD along with the necessary manuals and other software. Before you can use the software, you must install it on your hard drive.

To run the *Si Programmer™* software, you must have a computer with the following requirements:

- Microsoft Windows 95, 98, 2000, ME, NT, XP or Vista.
- At least 256 MB memory.
- 20 MB available hard drive space.
- Mouse or other input device
- CD or DVD drive (or you can download *Si Programmer™* from www.applied-motion.com).
- A nine pin serial port must be available, preferably COM1. If you don't have a serial port, get a "USB Serial Adapter."

The software installation is highly automated, like most Windows programs, so the process is simple:

- Put the CD into your CDROM or DVD drive.
- A CD Browser should appear within 60 seconds.
- Select "Install Software".
- From the next screen, select "Si Programmer".

If the CD does not autostart the autoplay feature may have been disabled on your PC. This will continue to cause problems for you until you turn Autoplay back on. Please consult Help under your Windows Start menu or contact the manufacturer of your PC. If you are in a hurry (and who isn't?) you can manually launch the CD by double-clicking the My Computer icon. Then right click the Si™ CD icon and choose Autoplay.

You can also download our software and manuals from www.applied-motion.com.

If you encounter errors during installation, it is usually due to a lack of memory or conflicts with other programs that are already running on your PC. If you experience an error while installing the programming software, quit all other Windows applications and try again. Holding down the ALT key and pressing TAB will show you all the programs currently running on your PC. Laptop computers generally present the biggest challenge to installation, as they often come pre-loaded with programs that automatically execute on start-up such as Microsoft Office and battery managers. Furthermore, laptops usually have the least memory.

If all else fails, restart your computer and press the F8 key when you see the message "Starting Windows..." Windows will start in "Safe Mode" which generally solves the installation problem. Once you have successfully installed the software, you can reboot and operate Windows normally.

The programming software will install more easily and run much faster if you have more memory.

Several example programs are installed with your programming software. It's a good idea to load some of the examples and look at them; they may help you with your own application.

Display Settings

The *Si Programmer™* works well with any display resolution. At 640 x 480, the *Si Programmer* will exactly fill your screen. At higher resolutions, like 800 x 600 or 1024 x 768, there will be room left over on the screen for other applications, or to expand the *Si Programmer* window so you can see more program lines. 16 bit color setting, or higher, is recommended.

Information in the program window will not display correctly if your display is set for "Large Fonts."


Programming Notes:

- 1. Always apply power to Si hardware after the *Si Programmer™* software is running on your PC.**
- 2. When downloading to the indexer/drive, make sure the JOG inputs are not activated. If in doubt, remove the JOG CW and JOG CCW connector plug.**

Please use the “Small Fonts” setting when running the *Si Programmer* software. The display settings are found under “Start...Settings...Control Panels”.

Connecting to your PC

- Locate your computer within 6 feet of the Si™ hardware.



- Your Si™ product was shipped with a black adapter plug connected to a telephone line cord. Plug the large end into the COM1 serial port of your PC and the other end into your indexer. Secure the adapter with the screws on the sides. If the COM1 port on your PC is already used by something else, you may use the COM2 port for the Si™ Indexer. On some PCs, COM2 will have a 25 pin connector that does not fit the black adapter plug. If this is the case, and you must use COM2, you will have to purchase a 25 to 9 pin serial adapter at your local computer store.

Never connect the Si™ Indexer to a telephone circuit. It uses the same connectors and cords as telephones and modems, but the voltages are not compatible.

You may also need to set the COM port in the Windows software. When the software is loaded, it looks for the first available COM port, but doesn't always find the one you've plugged into.

You can choose the port yourself by clicking on one of the “COM port” option buttons. If the port exists and is not already in use, the programming software will use it to communicate with the Si™ Indexer.

What if my PC has no Serial Port?

You can use a USB port as a serial port if you obtain a “USB Serial Converter”, which looks like a short cable. We like the Port Authority “USB Serial DB9 Adapter”, from CablesToGo.com, part number 26886. It's inexpensive (usually under \$30) and works great.

Programming Notes:

- 1. Always apply power to Si hardware after the Si Programmer™ software is running on your PC.***
- 2. When downloading to the indexer/drive, make sure the JOG inputs are not activated. If in doubt, remove the JOG CW and JOG CCW connector plug.***

Programming

You may have noticed that the Si™ Indexer doesn't have any switches or knobs on the front panel. There are also no jumpers inside. Just about everything you want the Si™ to do is controlled by software. The *Si Programmer™* software that comes with the drive allows you to set the motor current, the step resolution, jogging parameters and limit switch polarity. It also helps you write complex motion control and machine interaction programs.

Note: *If you are using a BLU or SV servo drive and it hasn't been configured and tuned yet, you should skip ahead to the "Servo Tuning and Motor Set Up" section, and come back here when you're done.*

The *Si Programmer™* has a user program capacity of 100 lines. In this space, you can design one or more motion and machine control programs. More than 20 commands, or instructions, are available for this purpose.

Six of the instructions involve pure motion: *Feed to Length*, *Feed & Set Output* and *Feed & Return* are fixed distance moves. *Feed to Position* is a move to an absolute position. *Feed to Sensor* and *Feed to Sensor & Return* move relative to a sensor that is wired to one of the inputs. *Seek Home* searches for a home sensor, "bouncing off" the limits if necessary to find it.

Two instructions handle timing: *Wait Time*, which causes your program to stop for a specified amount of time. *Wait Input* waits for one of the inputs to reach a specified state before continuing the program.

Five instructions control program flow. *Go To* makes the program jump to a particular line. *If Input* jumps to a line if one of the inputs meets a specified condition, otherwise, the program just goes on to the next line. *Repeat* and *End Repeat* set up a loop wherein you can repeat the same instructions many times. If your program terminates a Repeat loop before it's finished (using an *If Input* instruction) you can reset the loop count with a *Reset Repeat Loop* instruction.

One instruction, *Set Output*, allows you to signal other equipment that you have reached a particular place in your program.

Using the *MMI Prompt* instruction with the optional MMI (man-machine interface, or operator panel), the operator can enter distances, speeds and repeat loop counts on a keypad. The drive can also display messages for the operator, pause the program until the operator presses the ENTER button, or ask the user to make a decision and respond by pressing the YES key or NO key.

A *Comment* instruction allows you to leave notes in your program so that it's easier to understand.

Set Absolute Position lets you define the present motor position in absolute terms.

Change Current gives you more control over the motor current - turning the current off, resuming the previous level, or defining a new current setting - anywhere in the program.

Hand Wheel lets the user position the motor and load precisely using a CNC hand wheel.

By combining the instructions in different ways, you can construct a nearly infinite variety of useful programs and motion profiles. Before entering your program, you'll want to spend a little time thinking about how to accomplish your objective. Then, once you have a clear idea of what to do, you can begin entering the instructions and parameters.


Note: *some programming features will not be available if you are using an older Si™ drive because the drive firmware doesn't support them.*

Which Software Version do I Have?

There are actually two software programs associated with the Si™ Indexer. The first is the *Si Programmer™*



Windows program that you installed on your PC from the floppy disks. After you double click on the icon and program begins to load, you'll see a picture of a lightning storm. The software version is displayed at that time. After the program is loaded, you can click on the Applied Motion Products logo to see the software version, our internet address and our phone and fax numbers.



A second software program resides in a chip inside the Si™ Indexer. Since software in a chip is usually called “firmware”, we will refer to it as firmware for the rest of this manual. It is the Si™ Indexer firmware that runs your drive and executes the program you've downloaded. When you connect your drive to the PC and turn the drive on, the drive firmware version is displayed near the top of the screen.


If you are using an ST, SV, STAC6 or BLU drive, then an additional firmware program resides in the drive's Digital Signal Processor. To discover the firmware version of the DSP, click on the Si firmware version shown on the main window.

If you call your distributor or Applied Motion Products for support, we will want to know the versions of both the *Si Programmer™* and the drive firmware, so please write them down before calling.

You may have noticed the list box just above the firmware version number. The *Si™* software is designed for programming all of our *Si™* drives. Please select the appropriate drive from this list before you begin programming.

Entering Your Program

If you installed the software back in the section entitled “Installing the Programming Software” then you're ready to go. If not, please go back and review that section.



To activate the software, click on the Start button, then Programs...Applied Motion Products...Si Programmer. The main programming window will soon appear, as shown on the previous page. The title bar will display the *Si Programmer™* software version.

If you have an Si™ Indexer connected to the PC, turn it on now. After you apply power, your computer should beep. The “Drive” box will display the version number of the Si™ Indexer firmware that’s in your drive.

If you don’t have any Si™ hardware connected to your PC, you can still write programs. Before you begin, you should select the appropriate Si™ device (Si5580, 7080i, etc) from the list box above the word “drive.” That way you will have access to the specific features of the hardware you plan to use.


Let’s enter a simple program. We’ll start with a simple time delay, by putting a *Wait Time* instruction on the first line.

Next to the large number 1 in the Program Window is a button showing a downward pointing arrow. That indicates that there is no instruction for that line. Anytime an Si™ program encounters a line without an instruction, it simply moves on to the next line, as the icon implies with the downward pointing arrow. After the program executes the instruction on line 100, it automatically jumps to line 1, unless the instruction on line 100 makes it jump somewhere else.

To enter an instruction on program line 1, click once on the program icon. You should now see the “Program Menu”, shown below.

Click on the button marked “Wait Time”. The Wait Time dialog box will appear. Enter 1 second in the text box and press OK.

The first line of your program should now display the Wait Time icon, and the description “Wait 1 second.”



Click on the icon button for program line 2. This time when you see the “Program Line...” box, click on Feed to Length. In the Feed to Length box, enter the distance as 20000, then slide the speed bar to 10 rev/sec. Click OK.

The second program line should now show the motor icon and the caption “CW 20000 steps, 10 rps.”


Click on the line 3 icon. Choose “Go To”. When you see the Go To dialog, the line number will already be set to 1. Click OK. Your program should now resemble the following:



If you have a motor connected to your drive, you can test the program now.

Set the current to match your motor's rated current. Then, click on the Download button near the middle of the screen. If your drive is on, and is connected properly, the download

box will appear and show you the progress of the download, which takes 1-3 seconds. (The transfer time is governed by the speed at which the Si™ Indexer can rewrite its internal, nonvolatile memory, and by the size of your program.) Once the download has been completed, you are ready to execute the program.



Press the Execute button. You'll see the execute box in the middle of the screen. *(If your indexer/drive has firmware prior to 1.40, you'll see a simpler execute box than the one shown here. Older drives are not able to send real time status information to the PC, and cannot respond to advanced commands like Pause and Single Step.)*

Every second, the motor should move one revolution. (Assuming that you have left the resolution setting at the default 20,000 steps/rev. If you have a servo drive, then 20,000 steps is probably more than one revolution.)

Not so exciting, perhaps, but you have to admit it was easy to do.

More complex programs are entered in the same manner, you just enter more lines and you'll be more concerned about the exact parameters and their importance in your application. We've designed the Si™ Indexer to be easy and fun to use. If you can think of anything we've forgotten, please give us a call or send a fax. We continuously improve our products, and are always developing new ones based on what we've learned from you, our customer.


Note: if you need to edit an instruction that's already in your program, and wish to go directly to the appropriate dialog box, hold down the shift key while you click on the instruction icon.

Copying Instructions

There may be occasions where you want to make an exact copy of an instruction, or perhaps a copy with only one or two parameter changes. The fastest way to copy an instruction from one line to another is to point the mouse at the instruction icon that you want to copy, and drag the icon onto another one elsewhere in the program. This is referred to as “Drag and Drop.”

For example, say you've entered a *Set Output* instruction on line 5 of your program, and you'd like an identical *Set Output* on line 11. Position the mouse over the *Set Output* icon on line 5, then click and hold the mouse button. Move the mouse until the icon is over the line 11 icon. Let go of the button, and the instruction with all of its parameters will be copied to line 11.

Inserting and Deleting Program Steps




Insert New Step

The time will no doubt come when you've entered many program lines only to realize that you need to add an instruction right in the middle. We could be cruel and tell you that you'll have to reenter most of the instructions to make room for the new one. But, in the spirit of making the Si™ Indexer easy to use, we've included a command to insert a new instruction anywhere in your program.

It's easy to do: just click on the program icon where you want the new instruction to go. You'll get the Program Line... dialog, as usual. Instead of choosing one of the 20 instructions, click on the command button marked "Insert." The instructions are reordered, and the line you need for your new program line is available.

You can then click on the open line and select an instruction as you normally would.



Delete Step

In addition to inserting a line in your program, you can delete one to make room for others farther down. You may, for example, have some available space in the middle of the program, but want to add an instruction near the end.

Click on a program line that you don't need. When the Program Line... dialog comes up, select "Delete." The line you selected for deletion will be gone, and all the other lines will move up one position, leaving a blank spot at the end of the program.

By combining insertions and deletions, you can place your program lines wherever and whenever you need to.

Protecting Your Program with a Password

Available on 1240i, 3540i, Si2035, ST5-Si, ST10-Si, SV7-Si, STAC6, BLuDC, BLuAC. Firmware version 2.21 or later is required.

Once you have completed and downloaded your program you may wish to protect it from prying eyes. You can do so by pressing the Ctrl and L keys at the same time (known as Control-L). The Si Programmer™ will ask you to type a four digit password. After you enter the password and click OK, you will no longer be able to upload or download from the drive.

To unlock the drive, press Control-U. You will be asked to enter your password and if you enter it correctly, the program will be unlocked. *What do you mean you forgot your password?* Well, I hope you saved a copy somewhere, because the only way you can unlock a drive without the right password is to enter 1234. The drive will be unlocked, but your program stored in it will be erased.


User Defined Units

The Si Programmer™ normally expects you to enter distances in steps and speeds in revolutions/sec. However, you can also define your own units.

To define your own unit, first enter a name in the name box. In the example at the left, the name is "inch." The name you enter cannot be longer than four characters.

Next, you must enter the number of motor steps in one of your units. For example, 20,000 steps/rev with a screw pitch of 2 turns per inch is

$$(2 \text{ revs/inch})(20,000 \text{ steps/rev}) = 40,000 \text{ steps/inch}$$



A screenshot of the 'User Units' dialog box. It has a title bar 'User Units' with a checked checkbox. Below the title bar, there are two input fields. The first is labeled 'name' and contains the text 'inch'. The second is labeled 'steps/inch' and contains the number '40000'.

Sometimes screw pitches are expressed as inches per turn (0.2 for example.) If that case, your steps/inch would be the steps/rev divided by the inches/turn.

Be sure to check the “User Units” check box. You will notice the units of the jog panel change from “rev/sec” to “inch/sec.” Any program instruction dialog you open will also be operating in inches and inch/sec.

Other choices of steps/rev can be useful when defining units. If you have an English screw and wish to work in millimeters, for example, setting the steps/rev to 25400 is helpful. Then the user unit definition for the 2 turn screw would be

$$(2 \text{ rev/inch})(25400 \text{ steps/rev}) / (25.4 \text{ mm/inch}) = 2000 \text{ steps/mm}$$

Note: If the Si™ hardware you are programming has firmware prior to version 1.28, you can still program it with user defined units, but when you download your program, the indexer will not remember your unit name and pitch. The program will execute correctly, but if you upload, the user unit definition will not upload with the rest of the program.

Front Panel STOP Button

Some Si™ products have a red button on the front panel marked “STOP.” This button can be used to interrupt motion at any time. After pressing the STOP button, the motor will stop and the front panel Power LED will then flash until the AC power is removed. If the indexer/drive is connected to a PC running the Si Programmer™, the software will alert the user on screen to the condition, and ask if you want to reset the indexer/drive from the PC.

Setting the Step Motor Current

The drive current must be set to match the motor. First, determine the rated current for the motor. If you are using one of the motors recommended in the User’s Manual for your Si™ indexer/drive, the User’s Manual lists the rated current. Otherwise, you’ll have to go by the manufacturer’s rated current, which is usually printed on the motor label. You can operate a motor at less than the rated current. It will have less torque than it would at the rated current, but will run cooler and make less audible noise.

Depending on how you connect the motor to the drive, the current setting on the drive may differ from the rated current of the motor. For example, if you’re using an Applied Motion motor, follow these rules:


Four lead motor: Use the rated current. The motor can only be connected one way.

Six lead motor: the nameplate current is for the center to end connection. If you choose to connect the motor in series, divide the current by 1.4.

Eight lead motor: the nameplate current is for center to end. For parallel connections, multiply the current by 1.4. For series divide by 1.4.

In the Si Programmer™ software, the current is controlled in the main window by the panel on the upper left side of the screen. To adjust the current setting, just slide the scroll bar left or right. Precise adjustments can be made by clicking on the arrows at each end of the scroll bar.

Note: current setting only applies to Si™ indexers with built-in drives, like the Si5580 and 7080i. The Si-100 does not have an internal motor driver, so the current setting has no effect on the Si-100.




Idle Current Reduction

Your drive is equipped with a feature that automatically reduces the motor current anytime the motor is not moving. This reduces motor and drive heating. For example, setting the idle current to 50% reduces drive heating by about 50% and lowers motor heating by 75%. This feature can be set at any of four levels: 0%, 25%, 50% and 100%. The 100% setting is useful when a high holding torque is required, as the drive does not reduce the current at all. The 0% setting is for applications in which no holding torque is required.

To minimize motor and drive heating we highly recommend that you use the idle current reduction feature unless your application strictly forbids it. The idle current setting is chosen using the option buttons in the motor current panel.

Setting the Servo Motor Current


The drive current must be set to match the motor. First, determine the rated current for the motor. If you are using one of the motors recommended in the User's Manual for your Si™ indexer/drive, the User's Manual lists the rated current. Otherwise, you'll have to go by the manufacturer's rated current, which is usually printed on the motor label. You can operate a motor at less than the rated current. It will have less torque than it would at the rated current, but will run cooler and make less audible noise. Servo drives have separate settings for continuous and peak current. The peak current only lasts for a few seconds but allows you to get extra torque from the motor for higher acceleration. Normally you would set the peak current to 2 or 3 times the continuous current, unless there is a mechanical limitation (such as a gearhead).



Microstepping (Step Motors Only)

Most non-microstep step motor drives offer a choice between full step and half step resolutions. In full step mode, both motor phases are used all the time. Half stepping divides each step into two smaller steps by alternating between both phases on and one phase on.

Microstepping drives like the Si5580 precisely control the amount of current in each phase at each step position as a



means of electronically subdividing the steps even further. All Si™ indexer-drives offer a choice of 13 step resolutions, starting at 2000 steps per revolution. The highest setting divides each full step into 254 microsteps, providing 50,800 steps per revolution when using a 1.8° motor.

Other Si™ products may offer a different selection of resolutions than the ones shown here. The Si™ Programmer automatically presents the resolutions that are available on your hardware if the model number of your indexer-drive is shown in the "drive box" near the top of the screen.

In addition to providing precise positioning and smooth motion, microstep drives can be used for motion conversion between different units. The 25,400 step/rev setting is provided as a means of converting motion from metric to English. (There are 25.4 mm per inch.) Other settings provide step angles that are decimal degrees (36,000 steps/rev makes the motor take 0.01° steps.) Some settings are used with lead screws. When the drive is set to 2000 steps/rev and used with a 5 pitch lead screw, you get .0001 inches/step. The selection of microstep resolution can be important if you are using the optional MMI, and plan to scale the distances or speeds that the user enters.

If in doubt, choose 20000 steps/rev. The motor will run smoother and more



quietly at 20000 steps/rev than at lower resolutions like 2000.

The microstep resolution of the Si™ Indexer is set using the programming software. The resolution appears at all times in the Steps/revolution panel on the left side of the main window. To change the resolution, click on the Change button and you'll see a dialog box with option buttons for each resolution. Click the one you want, then click on the OK button.

If you change the step resolution and there are motion instructions in your program, the software will warn you that the distances may need to be changed (because they are in steps). It also offers to automatically scale the distances so that the distance in revolutions remains the same.

Note: *If you are using an Si-100 indexer, you must also set the step resolution at the drive so that it matches the Si Programmer™ setting.*

Jogging

Two of the Si™ Indexer input terminals are provided for jogging the motor.

If the Si™ Indexer is connected to a PC with the programming software running, the jog inputs will function under two conditions:

- if the program is not executing (while connected to the PC) - *not available on all products*
- if the program is executing a *Wait Input* command.

If the Si™ Indexer is operating in stand alone mode (i.e. without a computer attached) then the jog inputs work when the program is executing the *Wait Input* instruction.

To set the Jog Speed and Jog Accel/decel rate, adjust the scroll bars in the main programming window.


We recommend setting the accel/decel to a modest rate. 25 rev/s/s usually works well unless you have a very high inertial load, in which case you should set it to a lower rate. The range of jog accel is 1 to 3000 rev/s/s.

The range of jog speed is .025 to 50 rev/sec. The speed you choose will depend on your application.

If you don't need to jog, you can use the jog inputs as input 5 and input 6, for use with *Feed to Sensor*, *Wait Input* and *If Input* instructions. The CW JOG input can be assigned as a general purpose input by checking the box marked "Make IN5/Jog CW a general purpose programmable input." The IN6/Jog CCW input can also be used as a general purpose programmable input. These settings are found in the Configure Inputs dialog.

If you have an Si™ indexer/drive with firmware version 1.40 or later, you can use the arrow keys on the optional man machine interface (MMI) for jogging. This is an option in the Wait for MMI Enter instruction.

Firmware versions 2.08 and later allow three choices of jog speed in the Wait Input and MMI Enter instructions: global jog speed (the one set by the main screen panel shown above), local jog speed (specific to each instruction) and MMI Jog Speed (uses an MMI speed variable to allow the user to enter a jog speed.)



Configure Inputs Dialog

On the main screen, just below the jog settings is the Configure Inputs button (it's labelled Configure I/O when you're programming a BLU servo drive). Clicking this button brings up the following dialog box (you won't see the right hand side unless you're programming a BLU servo):

Interrupt

If your drive has firmware version 2.08 or later, you can assign one of the inputs to interrupt your program and branch no matter what your program is doing. For example, your Si drive may be part of a larger material handling system. If something “downstream” of the Si drive cannot handle more product (perhaps a conveyor jammed, a box is full and has not been removed or a labeler has run out of labels or ink), you may want to command the Si drive to stop what it is doing and wait for the condition to clear.

Interrupts are set in the Configure Inputs dialog, as shown above.

The first step is easy: just choose an input and a condition for the interrupt. If a sensor closes when a fault occurs and that sensor is connected to input 3, choose “input 3” as the input and “low/closed” as the condition. Then select “Branch on interrupt” and choose a line number. That’s where you will put instructions to handle the interrupt “recovery”. Generally this means waiting for the interrupt condition to clear (a Wait Input instruction can do that), and then returning from the interrupt. This is where it gets a little tricky, so please read carefully.


Two Types of Interrupts

The Si drives support two different kinds of interrupts: Call interrupts and Go To interrupts. You’ll set the Configure Inputs dialog the same way for both. The distinction is in the way you build your “interrupt handler” (the instruction that you place at the interrupt branch address.)

Call

This type of interrupt uses the “Call/Return” mechanism to allow your program to return to whatever it was doing before the interrupt occurred. Sometimes this is referred to as “slide hold” because you can interrupt a move, then resume the move after the interrupt condition has gone away. Here’s how it works:


1. When the interrupt input matches the condition you specified, the drive stops whatever instruction it was executing, including any move.
2. The drive pushes a return address onto the Call Stack. If you don’t know what the Call Stack is, please read the section entitled “Call and Return.”
3. The program branches to your interrupt address. The interrupt is also disabled so that you don’t keep branching to the same address over and over again, with your program unable to do anything else. If your drive is still connected to your PC with the Si Programmer software running (we call this Development Mode), you will see the interrupt status change from “Enabled” to Disabled”.
4. You should wait for the interrupt condition to clear. If you are using an MMI, you may want to alert the operator.
5. Once the condition has cleared, use the Return instruction to resume your main program. Be sure to choose the option “Return from interrupt”, not “return from Subroutine.” This instruction will enable the interrupt and return to the instruction that was running when the interrupt first occurred. If this instruction is a Feed to Sensor, Feed to Position or Seek Home move, the move will usually reach its intended target. Feed to Length moves generally overshoot under these conditions because after the interrupt, the move starts over from the beginning. For example, if a 6 inch Feed to Length move was interrupted after going 3 inches, the total move distance will be 9 inches.
6. For a Call interrupt, do NOT use the Reset Interrupt as part of your interrupt handler or you will experience a stack underflow. Also, you don’t want the interrupt enabled until you return to the main program or the interrupt handler could be interrupted causing a big stack mess (BSM).



Go To

In many applications, it is better that the program not “pick up where it left off” after an interrupt. You may want to start your program over from the beginning, or you may wish to always resume from some other spot. Here’s what you do:

1. When the interrupt input matches the condition you specified, the drive stops whatever instruction it was executing, including any move.
2. The drive pushes a return address onto the Call Stack, which we will not actually use.
3. The program branches to your interrupt address. The interrupt is also disabled so that you don’t keep branching to the same address over and over again, with your program unable to do anything else. If your drive is still connected to your PC with the *Si Programmer™* software running (we call this Development Mode), you will see the interrupt status change from “Enabled” to Disabled”.
4. You should wait for the interrupt condition to clear. If you are using an MMI, you may want to alert the operator.
5. Once the condition has cleared, you need to turn the interrupt back on. The Reset instruction can do that. Be sure to choose the “Reset Interrupt” option. If you forget this instruction, the interrupt will only work once. Be sure to choose the “also reset call stack” option. That will remove the interrupt address from the call stack and prevent a stack overflow.
6. Use a Go To instruction to complete your interrupt handler.



Combining Subroutines and Interrupts

The Call Stack is five levels deep. The interrupt always uses one level, so if you are using both subroutines and interrupts in your program, be sure to use no more than four stack levels for your subroutines. That way even if you are “four levels deep” on your subroutine calls (a subroutine calling a subroutine which calls a subroutine) you will still have one stack level free for the interrupt.

Quick Decel Rate

When something unexpected happens you usually want to stop the motor quickly. The Quick Decel rate is used when a move is interrupted by an end of travel limit and when an interrupt becomes active. It is also used for servo faults and when you click the Stop button on the *Si Programmer's* execution status box. If you set the Quick Decel rate too high, a step motor could “break loose” and coast to a stop, though that usually won't happen unless you have a high inertia load. Servos are so responsive that a very high decel rate could cause damage to the mechanics of your system.

Limit Switches

The Configure Inputs dialog of the *Si Programmer™* software contains a panel for selecting the type of limit switches or sensors that you have.

If your switches will close when the motor reaches a limit, select the option marked “closed.” This is often referred to as a *normally open* switch. If your switches are closed when the motor is not at a limit, and will open when a limit is reached, select “open.” This type of switch is frequently called *normally closed*. If you're not using limit switches in your application, you can select “not used,” making the cw and ccw limit inputs available as inputs 7 and 8 for Wait Input and Feed to Sensor instructions. The limit inputs are always available for If Input instructions.

Earlier firmware versions stop the motor instantly with no decel ramp and always halt the program. The red Power LED on the front panel will flash, and no future motion is possible. You must remove power from the drive to reset this condition.

If the drive is connected to a PC, the programming software will alert the user to this condition and ask you if you want to reset the drive from the PC (instead of removing power).

What Happens When You Hit a Limit Switch?

If you are **jogging** (using the JOG CW or JOG CCW inputs or the MMI arrow keys) and you hit a limit, motion will be disabled in the direction that you were traveling. You can then jog in the reverse direction to back away from the limit.

During a **Seek Home** instruction, the motor will reverse direction when a limit is encountered, and continue seeking the home sensor.

If you encounter a limit during a **Feed to Length, Feed & Set Output, Feed to Position, Feed to Sensor, Feed & Return** or **Feed to Sensor & Return** move, the Si™ Indexer will immediately stop the motor.

If you are using drive firmware version 2.08 or later, the “Quick Decel rate from the Configure Inputs dialog will be used to decelerate the motor. What happens next depends on other settings of the Configure Inputs dialog. You can choose to halt the program. If so, your program and all motion will be stopped. The drive will flash the power LED and will perform no further action until power is cycled.

If you choose “stop motion, branch” in the Configure Inputs dialog, the motor will stop and the program will branch to the line you specify. You can put an “error recovery routine” at the branch line number to handle the limit problem.

Interrupt and Limit Branch

If you have chosen “branch on interrupt” and “branch on limit” in the Configure Inputs dialog, both events will

branch to the same program line. You may need to distinguish between the two events. If you are using the Call/Return style of interrupt, then you must have a Return from Interrupt instruction in your interrupt handler. But you must not allow the limit branch to encounter that instruction or you will underflow the call stack. You can use an If Input instruction to detect the limit and branch to a different set of instructions. If your limit condition is “low” at the limit, then use “If Input 7 or 8 low”. If your limit condition is “high” at the limit, then use “If Input 7 or 8 high” to detect the limit in your handler.

Motion Output (BLU Servo)

If you select this function, output Y2 will automatically close when the motor is at or near its target position. You define the meaning of “near” by entering a tolerance in encoder counts. The target position changes from the present position to the “end of move” position as soon as a new move begins. The motion output will not close in the middle of a move even if the servo position error is very low. The motion output is designed to tell another piece of equipment that you’ve “arrived.”

Motion Output (STAC6 & ST5/10)

The STAC6-Si offers four options for the function of output Y2. Choose “closed” if you want Y2 to be closed when the motor is moving and open at all other times. “Open” causes Y2 to be open when the motor is moving and closed at rest. “Tach” is useful if you want another piece of equipment, such as a PLC with a built-in counter, to know how fast the motor is moving. When the “tach” option is chosen, Y2 produces 100 pulses per motor rotation. For example, if the motor is rotating at 5.5 revs/second the tach frequency will be 550 Hz. Select “not used” if you want to control Y2 in your program by using *Set Output* instructions.

Motion Output (Y2)

- ☐ Closed when motor is moving
- ☐ Open when motor is moving
- ☐ Tach: 100 pulses/rev
- ☒ Not used

Brake Output (BLU Servo, STAC6 and ST5/10)

When power is removed from a motor (or when a fault occurs) the motor loses all torque. The load is then free to move if acted upon by an external force such as gravity or a spring. In applications where it is essential that the load not move when the motor is disabled, a brake is required. Sometimes the brake is added externally to the shaft or load; other times the brake is built into the motor. In either case, the brake holds position when power is removed and must be supplied with power to release and allow motion. A small amount of time is required for the brake to engage or release.

The BLU servo, STAC6 and ST drives can automatically control the brake by wiring a power supply and a power relay in series with the brake coil. Another power supply, usually 24 volts DC, is then wired in series with the Brake output (Y1) and the relay input coil. Please consult the drive hardware manual for wiring details.

If you want the drive to automatically release the brake when it powers up and to engage it when power fails and/or when the motor is disabled, just check the Brake Output box. You must also specify the “release time,” or how long you want the drive to wait before making any moves once it has sent the release signal to the brake. You must also tell the drive how long to wait for the brake to engage before turning off the motor.

Please note that in case of a drive fault, the motor must be disabled immediately. The brake engage time is ignored and some load slippage may occur.

Special STAC6 and ST5/10 Dialogs


When a STAC6-Si, ST5-Si or ST10-Si drive is selected from the drop down list, four special command buttons appear: Motor, Encoder, Alarms and Regen. Each button invokes a special dialog box for setting features unique to these drives.

The Encoder dialog is explained in the section “Encoder: STAC6 and ST5/10”.

The **Motor dialog** is used to select a motor from the list of Applied Motion Products motors that are designed for use with the drive. For optimal performance of the antiresonance and electronic damping features, you must also enter (or estimate) the load inertia.

We can't stress enough the wisdom in using one of the recommended motors with the STAC6. We're not just trying to make money here, we want your application to be successful and the odds of that are highest when you have a high quality motor whose torque, rotor inertia and harmonic waveform content are precisely known. Furthermore, our motors include shielded cables to reduce electrical emissions and enhance safety and come with prewired mating connectors which further reduces the risk of error. Having stated our case, if you still insist on using a different motor, it is possible. First you'll need some detailed information from the manufacturer, including electrical specification (holding torque, rated current and rotor inertia) plus a wiring diagram. And make sure the motor is constructed from high quality magnetic materials that are suitable for operation with 160 volt busses such as that of the STAC6. The ST5 and 10 operate at lower voltages than the STAC6 so the choice of motors is not as critical.

With this information in hand, choose the “custom motor” option and click on the Define Custom Motor button. You can enter the current, torque and inertia values into the Add New Motor dialog. For best smoothness of motion, you'll want to enter the harmonic distortion gain and phase. You may need to experiment by running the motor at a slow speed (typically 1 rev/sec) with different gain and phase values to see what works best. If you are at a loss for this data, set the gain and phase at 0.




If you plan to use the Encoder Stall Prevention feature (see the Encoder Dialog), you'll need to enter the maximum lead angle and the speed at which this "timing advance" peaks so that the drive knows when it is producing maximum torque. A typical motor produces maximum torque at low speeds with a 90° lead angle. To produce maximum torque at higher speeds, the lead angle must be increased because of inductance and back emf. Above a certain speed, further increases in lead angle produce no benefit, so you must tell the drive when to stop advancing the timing. In the example below, the lead angle is increased steadily from 90° at low speeds to 135° at 40 rev/sec, so you would enter "135 degrees at 40 rev/sec", as shown above.

If you are not using Stall Prevention, these values are not needed by the drive.

The Alarms dialog shows you a chart of the eight most recent alarm conditions. It also allows you to clear an alarm or to clear the entire history.

The alarms dialog also allows you to dedicate output Y3 to the task of signalling a fault condition to other electronic devices. You can also choose to branch to a particular line of your program should a fault occur.



Alarm History
✕

	1	2	3	4	5	6	7	8
motor stall								
CCW Limit								
CW Limit								
drive overtemp								
excess regen								
over voltage								
under voltage								
over current								
open motor winding								
bad encoder								
comm error								
save failed								
reserved								
motor resistance								
reserved								
reserved								

OK

Cancel

Help

Clear Alarm

Clear History

indicates an alarm. Code 1 is the most recent.

Drive Fault

If the drive faults:

☒ stop motion, halt program
☐ stop motion, branch to line 1

☐ close fault output (Y3)
☐ open fault output (Y3)
☒ neither

Servo Faults

If something goes wrong with your servo system, you're going to want to know about it. If you are still working in "development mode" (i.e. the drive is still connected to your PC with the *Si Programmer* software running) when a fault occurs, you'll get an on screen message. If you have a BLU servo drive with the latest firmware, you'll see a dialog box like the one to the right detailing any and all errors and providing you with an option to clear the fault.

You'll certainly want your Si™ program to take action if a servo fault occurs. The default action is to halt the motor and freeze your program. The drive will then display an alarm code on the front panel. Front panel alarm codes are shown on the next page.

You may also choose to branch to a program line if a servo fault happens. That way you alert the machine operator via the option MMI or you can automatically send a hardware signal using the Fault output (Y3 on the main board). If you are able to fix the problem, the servo can be re-enabled by the *Change Tuning* instruction if the Servo On option is selected.

If your drive has been operating "stand alone" and errors have occurred, you can connect the drive to the Si Programmer and have a look at the eight errors. Just power up the drive with *Si Programmer* present and click on Alarm History.

Servo Fault

If the servo faults:

☐ stop motion, halt program

☒ stop motion, branch to line

☐ close fault output (Y3)

☐ open fault output (Y3)

☒ neither

Servo Error

A Servo Fault has occurred. Alarm codes are displayed below:

Position Limit	<input type="checkbox"/>	<input type="checkbox"/>	motor short
CCW Limit	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bad hall sensor
CW Limit	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	bad encoder
drive overtemp	<input type="checkbox"/>	<input type="checkbox"/>	comm error
excess regen	<input type="checkbox"/>	<input type="checkbox"/>	save failed
over voltage	<input type="checkbox"/>	<input type="checkbox"/>	timing wiz failed
under voltage	<input type="checkbox"/>	<input type="checkbox"/>	current foldback

☒ indicates an alarm.

Alarm History

	1	2	3	4	5	6	7	8
Position Limit								
CCW Limit	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
CW Limit	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
drive overtemp								
excess regen								
over voltage								
under voltage								
motor short								
bad hall sensor								
bad encoder		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
comm error								
save failed								
timing wiz failed								
current foldback								
reserved								
reserved								

Code 1 is the most recent.
☒ indicates an alarm.

Front Panel Error Codes

BLuDC servo drives use red and green LEDs to indicate alarm codes. In the event of an error, the green LED on the main board will flash one or two times, followed by a series of red flashes. The pattern repeats until the alarm is cleared.

Code	Error
1 red, 1 green	position error exceeds fault limit
2 red, 1 green	ccw limit
2 red, 2 green	cw limit
3 red, 1 green	drive internal temperature exceeds 85°C
3 red, 2 green	motor over temperature
3 red, 3 green	blank Q segment
4 red, 1 green	power supply voltage is more than 55 VDC
4 red, 2 green	power supply voltage is less than 18 VDC
5 red, 1 green	over current / short circuit
5 red, 2 green	current foldback - peak current I ² T time exceeded
6 red, 1 green	bad commutation(Hall) signal
6 red, 2 green	bad encoder signal
7 red, 1 green	serial communication error
7 red, 2 green	flash memory error

BLuAC servo drives have a seven segment LED that displays alarm codes using numbers and letters, as shown here. Fault codes blink and disable the motor. Alarms do not blink and do not disable the motor.

Code	Meaning
P	Fault: servo position error limit exceeded
L	Alarm: the ccw limit has been triggered
J	Alarm: the cw limit has been triggered
t	Fault: the Drive PCB temperature has exceeded 75° C. This will cause the drive to fault and cannot be cleared until the temperature drops below the limit.
O	Overvoltage fault: the DC Bus voltage exceeded 400 Volts
U	Under voltage alarm: the DC Bus voltage has gone below 100 Volts.
C	Overcurrent/short circuit fault: the motor phase current has exceeded the 20 amps rms
c	Peak current alarm: peak current I ² T time exceeded, current temporarily reduced to continuous setting
H	Commutation fault: hall sensor inputs are incorrect. May indicate a failed sensor or bad cable.
E	Encoder fault: encoder not providing correct signals or single ended encoder used but not selected.
F	Flash or eeprom memory fault
r	Regeneration fault: while attempting to “dump” power into the regeneration shunt resistor the device limits were reached, or there is no regeneration shunt resistor attached.
d	servo disabled
o	Si subroutine stack overflow
u	Si subroutine stack underflow
-	Serial communication overrun or bit rate error
h	Attempt to use drive with outdated version of Si Programmer
1	The drive is in positioning mode. This is the mode used when performing “point to point” moves.
2	The drive is in velocity or jog mode.
3	The drive is in torque control mode.
4	The drive is in Step and Direction Control Mode. This is the mode used for “Encoder Following” or Positioning using Step and Direction inputs.
5	Si™ positioning mode. You will see this indication most of time your Si program is operating.

STAC6-Si has a two color (red/green) LED to indicate status and alarm codes. A flashing green LED indicates that the drive is operating normally with the motor energized. Solid green means the motor is disabled.

In the event of an error, the green LED on the main board will flash one, two or three times, followed by a series of red flashes. The pattern repeats until the alarm is cleared.

Code	Error
1 red, 1 green	motor stall (when using optional encoder)
1 red, 2 green	move attempted while motor disabled
1 red, 3 green	subroutine stack overflow
2 red, 1 green	ccw limit
2 red, 2 green	cw limit
2 red, 3 green	subroutine stack underflow
3 red, 1 green	drive internal temperature exceeds 85°C
3 red, 2 green	excess regen
4 red, 1 green	power supply overvoltage
4 red, 2 green	power supply undervoltage
4 red, 3 green	bad instruction in Si program (memory or software error)
5 red, 1 green	over current / short circuit
5 red, 2 green	motor resistance out of range
5 red, 3 green	Si firmware is incompatible with DSP firmware
6 red, 1 green	open motor winding
6 red, 2 green	bad encoder signal
7 red, 1 green	serial communication error

ST5-Si and ST10-Si have separate red and green LEDs to indicate status and alarm codes. A flashing green LED indicates that the drive is operating normally with the motor energized. Solid green means the motor is disabled.

In the event of an error, the green LED on the main board will flash one, two or three times, followed by a series of red flashes. The pattern repeats until the alarm is cleared.

Code	Error
1 red, 1 green	motor stall (when using optional encoder)
1 red, 2 green	move attempted while motor disabled
1 red, 3 green	subroutine stack overflow
2 red, 1 green	ccw limit
2 red, 2 green	cw limit
2 red, 3 green	subroutine stack underflow
3 red, 1 green	drive internal temperature exceeds 85°C
3 red, 2 green	internal voltage error
4 red, 1 green	power supply overvoltage
4 red, 2 green	power supply undervoltage
4 red, 3 green	bad instruction in Si program (memory or software error)
5 red, 1 green	over current / short circuit
6 red, 1 green	open motor winding
6 red, 2 green	bad encoder signal
7 red, 1 green	serial communication error
7 red, 2 green	flash memory error

SV7-Si has separate red and green LEDs to indicate status and alarm codes. A flashing green LED indicates that the drive is operating normally with the motor energized. Solid green means the motor is disabled.

In the event of an error, the green LED on the main board will flash one, two or three times, followed by a series of red flashes. The pattern repeats until the alarm is cleared.

Code	Error
1 red, 1 green	position error fault
1 red, 2 green	move attempted while motor disabled
1 red, 3 green	subroutine stack overflow
2 red, 1 green	ccw limit
2 red, 2 green	cw limit
2 red, 3 green	subroutine stack underflow
3 red, 1 green	drive internal temperature exceeds 85°C
3 red, 2 green	internal voltage error
4 red, 1 green	power supply overvoltage
4 red, 2 green	power supply undervoltage
4 red, 3 green	bad instruction in Si program (memory or software error)
5 red, 1 green	over current / short circuit
5 red, 2 green	peak current foldback
6 red, 1 green	bad hall pattern
6 red, 2 green	bad encoder signal
7 red, 1 green	serial communication error
7 red, 2 green	flash memory error

Other Si drives with firmware 2.20 or later:

Code	Error
2 red, 1 green	ccw limit
2 red, 2 green	cw limit
1 red, 3 green	subroutine stack overflow
2 red, 3 green	subroutine stack underflow
4 red, 3 green	bad instruction in Si program (memory or software error)
7 red, 1 green	serial communication error

Using the Optional MMI


Si™ drives are available with an optional MMI (Man Machine Interface), sometimes called an operator panel. The MMI attaches to the same RS-232 port that you use to connect to your PC. The MMI has a four line liquid crystal display (LCD) and 20 keys for entering data. There are seven things you can do with the MMI:

- 1) *You can display a message on the LCD.* You might want to identify your machine (“ABC Bottle Filling Co. Model 20”) or display a status message (“Machine Running - Status OK”).
- 2) *You can pause your program until the user presses ENTER.* For example, if you were applying preprinted labels, eventually you’ll want to halt the process until the operator loads a new roll of labels.
- 3) *The MMI can ask the user to make a decision.* For example, you might want to offer the user an option, like changing set up parameters, that can be responded to by pressing the yes or no keys.
- 4) *The user can be asked to enter a move distance.* If you want to build a machine that feeds out material and then cuts it off, the operator can specify how long the resulting material will be.
- 5) *The user can be asked for a move speed.* This option allows the operator to adjust a feed rate, flow rate or other motor speed related setting.
- 6) *The user can be asked for a repeat count.* You can let the user set the number of parts that are processed. You can also combine a repeat loop with a *Wait Time* instruction to adjust dwell time.
- 7) *You can display a menu, wait for the user to press a numeral key, then branch to a corresponding program line.* Any or all of the keys 1 - 8 can be used, each with it’s own branch address.


If you are thinking ahead at this point, you might ask “If the MMI plugs into the same port as the PC, how can I run a program from the PC that uses the MMI?” Like most features of the Si™ software, it’s simple. If you press the Execute button and the program in your drive contains any MMI instructions, you will see a different execute box on your screen. The MMI execute box looks and acts like the real MMI: it will display messages, and you can click on the buttons to enter data. Like the other execute box, there is a display showing the status of inputs and outputs, and a control panel that allows you to interrupt, single step, or restart your program at any time.

We provided the emulated MMI to save you the expense of a second RS-232 port on your Si™ Indexer. It also allows you to try out the MMI before buying one.

Note: If your indexer/drive firmware is prior to 1.40, you won’t see the status display, because your drive is not able to provide real time status information to the PC. Instead, you’ll just see the MMI Emulator.



How to display a message on the MMI




- Click on a program line icon
- Select the MMI Prompt instruction
- Type "Machine Running Status OK" in the text box
- Select the "Display Text Only" option button
- Click the OK button
- The message will stay on the LCD until another instruction uses the MMI.

If you have drive firmware 2.10 or later, you can also display an MMI variable on line 3 or on line 4. Just select the variable - the *Si Programmer™* software will determine what type of data it is (speed, distance or count) and apply the proper scaling.

You can also display a variable and the current repeat loop count. For example, you may want to display the total counts programmed and the present count. To do this, check the "Display a Variable" box, select the variable Count1 and choose line 3. Later in your program, when you set up the Repeat instruction, choose the same variable (Count1) and select "display loop count on MMI line 4".

How to pause until user presses ENTER



- Select the MMI Prompt instruction
- Type “Please reload labels, then press ENTER” in the text box
- Select the “Display text & wait for enter” option button

If you want the user to be able to jog the motor using the MMI arrow keys, check the box marked “Allow jogging on MMI arrow keys.”

- Click OK

Multiple Jog Speeds


Drive firmware version 2.08 and later allows you to choose from multiple jog speeds. You can still use the “global” jog speed, as specified on the main screen. You can also select a fixed “local” jog speed that can be unique to each Wait Input instruction. This allows you to build a program with fast (rapid traverse) and slow (creep) jog speeds.

You can also select an MMI variable as the speed. This, in combination with an MMI Speed instruction, allows the operator of your system to enter one or more jog speeds.

Display Variable


If you have drive firmware 2.10 or later, you can also display an MMI variable on line 3 or on line 4. Just select the variable - the *Si Programmer™* software will determine what type of data it is (speed, distance or count) and apply the proper scaling.

How to let the user make a decision (MMI branching)



- Put an MMI Prompt instruction on line 1
- Type “Change setup parameters? (press yes or no)” in the text box
- Select the option button “Display text, wait for yes/no & branch on yes”
- In the line # box, type 12
- Click OK
- Starting on program line 12, place your parameter setting instructions.
- At the end of your parameter setting instructions, place a Go To line 2 instruction.

How to ask the user for a move distance



- Select an MMI Prompt instruction
- Type “Enter part length, in inches” in the text box
- Select the option button “Display text and get distance”
- Enter a scale factor, or, if you’re using User Defined Units, select “user defined units - MMI entries will be in inch” for automatic scaling.
- Enter upper and lower limits (in this example, we want to allow the operator to enter distances between 0.5 and 12 inches)
- Select an MMI variable to store the distance in (we chose Dist1 this time, but any of the eight MMI variables is acceptable for storing any type of data)
- Later in your program, you’ll need a Feed instruction (Feed to Length, Feed & Return, etc) that uses the Dist1 variable for distance.

How to get a speed from the user

The screenshot shows the 'MMI Prompt' dialog box. It has a title bar with a close button. Below the title bar is a section 'Use the Man Machine Interface' with an OK button. There are several radio button options: 'Display text only', 'Display text & wait for enter', 'Display text, wait for yes/no & branch on yes', 'Display text & get distance', 'Display text & get speed' (which is selected), and 'Display text & get repeat count'. To the right of these options is a 'Line #' field with the value '1' and a 'Cancel' button. Below the radio buttons is a 'Text to display on MMI' text box containing the text 'Enter the flow rate, in gallons/minute'. At the bottom, there are 'Scaling' and 'Limits' sections. The 'Scaling' section has a radio button for 'multiply MMI entries by' with a value of '10' and a note 'to get rev/sec', and another radio button for 'user defined units - MMI entries will be in inch/sec'. The 'Limits' section has 'Upper limit' set to '5' and 'Lower limit' set to '1', both with units of 'rev/sec'. On the right side, there is an 'MMI variable' section with a 'Save data as' dropdown menu set to 'Speed1'.

The screenshot shows the MMI screen. The top section is a light blue box with the text 'Enter the flow rate, in gallons/minute' and the value '2.75' displayed below it. Below this is a numeric keypad with buttons for digits 1-9, 0, a decimal point, and function keys: up arrow, down arrow, left arrow, right arrow, YES, NO, SPACE, BKSP, and ENTER.

- Select an MMI Prompt instruction
- Type “Enter the flow rate, in gallons/minute” in the text box
- Select the option button “Display text and get speed”
- Enter a scale factor (in this example, one gallon/minute equals 10 revolutions/sec of the motor)
- Enter upper and lower limits (in this example, we want to allow the operator to enter flow rates between 1 and 5 gal/min)
- Select an MMI variable to store the speed in (we chose Speed1)
- Later in your program, you’ll need a Feed instruction (Feed to Length, Feed & Return, etc) that uses the Speed1 variable for speed.

How to get a repeat count from the user


The screenshot shows the 'MMI Prompt' dialog box. It has a title bar with a close button. Below the title bar is a section 'Use the Man Machine Interface' with an OK button. There are several radio button options: 'Display text only', 'Display text & wait for enter', 'Display text, wait for yes/no & branch on yes', 'Display text & get distance', 'Display text & get speed', and 'Display text & get repeat count' (which is selected). To the right of these options is a 'Line #' field with the value '12' and a 'Cancel' button. Below the radio buttons is a 'Text to display on MMI' text box containing the text 'How many parts should we run?'. At the bottom, there are 'Scale' and 'Limits' sections. The 'Scale' section has a radio button for 'Multiply input data by' with a value of '10'. The 'Limits' section has 'Upper limit' set to '500' and 'Lower limit' set to '1'. On the right side, there is an 'MMI variable' section with a 'Save data as' dropdown menu set to 'Count1'.

The screenshot shows the MMI screen. The top section is a light blue box with the text 'How many parts should we run?' and the value '150' displayed below it. Below this is a numeric keypad with buttons for digits 1-9, 0, a decimal point, and function keys: up arrow, down arrow, left arrow, right arrow, YES, NO, SPACE, BKSP, and ENTER.

- Select an MMI Prompt instruction
- Type “How many parts should we run?” in the text box
- Select the option button “Display text and get repeat count”
- Enter upper and lower limits (in this example, we want to allow the operator to enter a number between 1 and 500)
- Select an MMI variable to store the count in (we chose Count1)
- Later in your program, you’ll need a Repeat instruction that uses the Count1 variable for the repeat count.

How to create an MMI Menu

Note: You need firmware version 1.41 or later to execute the MMI Menu function.



- Select an MMI Prompt instruction
- Select the option button “MMI Menu...”
- Type your menu text in the text box (you can enter up to four lines)
- Check the boxes indicating which numeral keys you want to use (in this example, we used 1,2,3 and 4)
- Assign a program line number to each key (we used 10, 20, 30 and 40)
- Later in your program, you’ll need to put instructions at each of the lines you’ve specified. These are the instructions that will execute if the user presses the appropriate key on the MMI. For example, when the user presses ‘1’, the program will branch to line 10.

Note: if you add extra spaces to your display text to get the look “just right”, watch out: sometimes the *Si Programmer™* removes those spaces when you reopen the instruction dialog. It is safer to format your text using other characters, like ‘.’ (period) or ‘_’ (underscore).

Making Your Move



MMI Prompt

The *MMI Prompt* instruction is used with the optional MMI (Man Machine Interface). MMI prompts allow your program to display messages on the MMI screen, and can gather data from the operator to be used by other instructions. The MMI can also pause the program until the user presses the ENTER button. It can allow the user to make a decision, then press the YES or NO button. If the user presses YES, the program branches to another program line. If the user presses NO, the program goes to the next line.

If you just want to display a message, such as “Machine Running - Status OK”, put an *MMI Prompt* instruction in your program at the point where you want the message to appear. Check the option button marked “Display Text Only” and type in your message. Once the *MMI Prompt* instruction has been executed, the message will stay on the screen until changed by another instruction that uses the MMI display.

If you want the operator of the machine you're building to be able to change parameters like distance, speed or repeat count, you'll need an *MMI Prompt* to ask the user for data and to store it in nonvolatile memory. In this case, click on the option button for the type of data you want: distance, speed or repeat count.

You'll need to set upper and lower limits. The *MMI Prompt* instruction will check the data that's entered against the limits you've specified, and tell the user if a value is out of range. For example, if you set the *MMI Prompt* to gather a repeat count, and you've set the upper and lower limits to 100 and 1, the instruction will not

accept any value bigger than 100 or smaller than 1.

You also must tell the *MMI Prompt* instruction where to store the data in nonvolatile memory. There are eight locations to choose from. They are named Dist1, Dist2, Dist3, Speed1, Speed2, Count1, Count2 and Count3. Remember where you told the *MMI Prompt* to put the data. When you set up an instruction to use data from an MMI variable, you must tell that instruction which variable to use (Dist1, Dist2, etc.)

For example, If you want the operator to be able to set the number of parts your machine produces in a given run, put an *MMI Prompt* instruction in your program to ask for a repeat count and to save it as Count1. Somewhere else in your program you'll set up a Repeat loop to process the parts. The loop will start with a *Repeat* instruction, one that you've configured to get its repeat count from the MMI variable Count1. You can even display the loop count on the MMI as your program runs. (*Note: you need an indexer drive with firmware version 1.40 or later to display the loop count on the MMI.*)

Scaling

The Si™ indexers work internally in steps and revolutions per second. The *MMI Prompt* can accept data from the user in other units (like inches or inches/sec) and automatically scale the data to internal units. There are two ways to do that.

The easiest method of scaling is to set up user units on the main screen. That way your entire program can be entered in your units. See page 14 for an explanation of user defined units.

Another way to scale user entries is to enter a scale factor directly into the *MMI Prompt* dialog box. That way you can use different scale factors in different *MMI Prompts*.

Scaling is only available when gathering distance or speed data.

Other Uses of MMI Prompts

If you want to pause your program until the user presses the ENTER key on the MMI, choose the option marked "Display text & wait for enter." If you wish, you can allow the operator to use the MMI arrow keys for jogging. (*Note: you need an indexer drive with firmware version 1.40 or later to do MMI arrow key jogging.*)

To allow the user to make a decision, select "Display text, wait for yes/no & branch on yes." Be sure to enter a line number in the Line # box. The program will jump to that line if the user presses YES. If the user presses NO, the program will execute the next line after the *MMI Prompt*.

The MMI Menu option lets you assign line numbers to as many as eight numeral keys, and display text on all four lines of the MMI. When the operator presses one of the numeral keys, the program branches to the corresponding line. This is an easy way to set up a menu driven system.

If you have drive firmware 2.08 or later, you can also display an MMI variable on line 3 or on line 4 if you are using the MMI Text Only or MMI Wait Enter options. Just select the variable - the *Si Programmer™* software will determine what type of data it is (speed, distance or count) and apply the proper scaling.

Securing Your Machine Setup

MMI Prompts are often used for machine set up. In some cases, it is necessary to prevent the machine operator from changing these settings. The Si Programmer does not provide password protection for MMI entries, but a mechanical "key switch" can be used for this purpose. The key switch should be wired to one of the programmable inputs of your Si™ drive. (Please refer to your drive's hardware manual for wiring details.) Place an If Input instruction in your program to jump over the MMI Prompts if the switch is in the locked position.

To see more examples of *MMI Prompts*, read the section *Using the Optional MMI* or load the sample programs that are installed with the *Si Programmer*.



Feed to Length

The *Feed to Length* instruction is used for point to point moves. If you just want to move the motor a fixed number of steps, this is the instruction to use. You can also use speed or distance data that was previously gathered by an *MMI Prompt* instruction.

When you click on the *Feed to Length* button in the Program Line... dialog box, you'll see the *Feed to Length* dialog box appear. This is where you enter the parameters for the move.

Distance - this is the number of motor steps you want to move. The maximum number is 16,000,000. If you

select the check box marked "Get distance from MMI", you can choose one of the eight MMI variables as the distance. Please note that checking "Get distance from MMI" does not automatically make the Si™ Indexer stop and ask the user for an entry. You'll need an *MMI Prompt* instruction somewhere else in your program for that.

Speed - this is the maximum speed you want the motor to go, in revolutions per second. You can set the speed anywhere between .025 and 50 rev/sec, in increments of .025 rev/sec. Servo drives have a speed range of .025 to 100 rev/sec. If you select the check box marked "Get speed from MMI", you can choose one of the eight MMI variables as the speed.


You can also reduce speed during the move by checking the box marked "Reduce speed during move." This is useful for applications where a tool may need to approach a work piece quickly, but slow down just before making contact.

Accel - motors cannot achieve a high speed instantly. The indexer-drive must gradually accelerate the motor to speed. The rate at which you can accelerate depends on the inertia of the motor and load, the torque available from the motor, and how fast you want it to go. You may need to experiment to find this out. The Si™ Indexer has an acceleration range of 1 to 3000 revs/sec/sec.

Decel - this is the rate at which the drive decelerates to a stop at the end of the move. It's also the rate at which the motor reduces speed if you choose that option. The range is the same as for acceleration. Because friction encourages a motor to stop, you can usually set decel higher than accel.

Direction - you can choose cw or ccw as the direction for the move. Just dot the appropriate circle by clicking on it.

Analysis - Click on this tab to see a speed vs time graph of your move. It also provides some useful statistics about the move, such as the duration of the move and the portion of time spent accelerating and decelerating. You can also select a plot of speed vs distance.





Feed & Set Output

The Feed and Set Output instruction is provided for two reasons. First, it allows you to combine a Feed to Length instruction with a Set Output instruction, making your program shorter. Feed to Length and Set Output are frequently used in combination because you want your Si™ product to signal another device when it finishes a move.

The second reason the *Si Programmer™* has a Feed & Set Output feature is for manufacturing throughput.

Feed to Length & Set Output
Move Motor Fixed Distance & Set Output

Move Parameters

Distance: 3.0 inch

Speed: 5.00000 inch/sec

Accel: 100.0 inch/sec/sec

Decel: 100.0 inch/sec/sec


Output Parameters

☐ Get distance from MMI
Name: Dist1

☐ Get speed from MMI
Name: Speed1

Direction

☒ CW
☐ CCW



The Si™ indexer may be advancing a part which will then be processed by another device, for example feeding material to be cut off by blade. If the blade requires a little time to approach the material, you'd like to trigger the blade before you're done advancing the material. That way, you can process more pieces in the same amount of time.

Feed & Set Output allows you to set an output high or low at any point during the move.

Feed to Length & Set Output
Move Motor Fixed Distance & Set Output

Output Parameters

☐ Set output at end of move

☒ Set output during move

2.2 inch

☐ Get output distance from MMI
Dist2

Condition

☐ High (open)
☒ Low (closed)
☐ High pulse
☐ Low pulse

2 msec

Output

☐ 1 ☒ 2 ☐ 3



Feed & Return

The *Feed & Return* instruction is used for point to point moves where you want to return to the starting point.

For example, if the motor was driving a cutoff knife, you would want to retract the knife after cutting.

Feed & Return requires many of the same parameters as *Feed to Length*: distance, speed, accel, decel and direction. For explanations of these, please refer to the *Feed to Length* section of the manual.

You'll also need to set the **return speed**. The range is .025 to 50 revolutions per second. Servo drives have a top speed of 100 rev/sec. In the case of the cutoff knife, you might want to feed slowly, as the knife is cutting, then retract quickly. Thus, you would set the return speed higher than the forward speed.

Return delay determines how long the Si™ Indexer waits between the end of the feed move and the start of the return. This could, for example, give the machine time to remove a part before retracting. Since a motor and load need time to “settle out” after moving, you should not set return delay to less than 0.2 seconds unless you are certain that your motor and load settle more quickly than normal.



Feed to Sensor

The *Feed to Sensor* instruction allows you to move the motor until an external event changes the state of an input.

One useful application for *Feed to Sensor* is when your motion distance varies. Let's say you are using a motor to dispense labels that come on a roll. You can't guarantee that the spacing of the labels is exact, so you don't want to simply feed out the same number of steps each time. Instead, you can put a sensor on the feed mechanism that "sees" the edge of each label and signals one of the Si™ Indexer inputs to stop motion.

Feed to Sensor will ask for many of the same parameters as the other feed programs: Speed, accel, decel and direction. You also need to specify a distance. That's because the Si™ Indexer must have enough space to decelerate to a stop once the sensor is tripped. The higher the speed, the longer it will take to stop. If the decel rate is increased, then the motor can stop in fewer steps. The "Minimum Distance" box tells you how many steps you must allow, based on the speed and decel rate that you've set. You can't set the distance to less than this minimum.

Move Motor a Fixed Distance Past Sensor

Distance

0.5

inch beyond sensor

☐ Get distance from MMI
Name

Dist1

Speed

5.00000

inch/sec

☐ Get speed from MMI
Name

Speed1

Accel

100.0

inch/sec/sec

Decel

100.0

inch/sec/sec

Sensor Input

☒ 1
☐ 3
☐ 5(cw/pg)
☐ 7(cwlim)

☐ 2
☐ 4
☐ 6(ccw/pg)
☐ 8(ccwlim)

Condition

☐ High
☐ Rising Edge

☒ Low
☐ Falling Edge

Minimum Distance based on speed and decel rate

0.125

Safety Distance

☐ If distance exceeds safety limit before sensor is found, stop motor and goto line

1

0.00005

inch

OK

Cancel

You'll also need to tell the Si™ Indexer which input the sensor is wired to and what input condition to look for. The four input conditions are:

High - move until the specified input reaches a *high* signal state. This is the default state of an input if nothing is connected to it.

Low - move until specified input is at a *low* signal state.

Rising Edge - move until the signal goes from low to high. This is similar to the high condition, but the difference is important. Let's say that you have a sensor wired to the Si™ Indexer that will go high when you want motion to stop. However, the sensor signal stays high after motion is complete, going low sometime later. This often happens in labeling applications where there isn't much space on the roll between labels. If you choose high as your input condition, the Si™ Indexer will complete the motion, then refuse to start again because the input signal is still high. If you choose rising edge, the Si™ Indexer would proceed with the input voltage high and stop when the sensor signal goes from low to high again.

Falling Edge - the opposite of rising edge. Si™ Indexer waits for an input voltage to go high, then low.

If you have a BLU-Si drive, you will see more input choices, including X0, the encoder index. With Applied Motion motors, X0 reads high when you are on the index and low everywhere else.

If you are concerned about your load never reaching the sensor (for example, if your sensor may fail or the load might jam up), check the box marked "If distance exceeds safety limit...". You can then enter a safe distance and specify a line number to which the program will branch if it can't find the sensor. For example, if you are sensing labels on a roll, and they are supposed to be about 1 inch apart, enter a safety distance of 3 inches. Then enter 20 as the branch line. On line 20, you will put some kind of error recovery routine, like an MMI Prompt telling the operator to check the label stock.

Note: the Si™ Programmer software will not let you enter a move distance that is less than the minimum deceleration distance for your chosen speed and decel rate. However, if speed or distance is set by an MMI variable, no such error checking is performed. It is your responsibility to choose an upper limit of speed and lower limit of distance so that an operator cannot enter an incorrect value. Failure to do this may result in unexpectedly long moves.



Feed to Sensor & Return

The *Feed to Sensor & Return* instruction is just like *Feed to Sensor*, but after the move the motor returns to the starting point.

Most of the parameters are the same as *Feed to Sensor*, but two new ones are added: the return speed and the return delay.

One useful application of *Feed to Sensor & Return* is a variable distance application. If we were building a

machine to cut fabric of different sizes, and the Si™ Indexer was driving the cutoff knife, we might want to set a sensor at the end of the cut off stroke. That way, we can manually adjust for the width of material we happen to be using on a particular day without having to reprogram the Si™ Indexer.

Each time it's triggered, the indexer-drive would feed until the knife trips the sensor, then return to the starting point.

You should beware of one thing: the maximum distance for any program is 16,000,000 steps. That's the longest distance the Si™ Indexer can track. If you move more than 16 million steps before you hit the sensor, the Si™ Indexer will not return to the correct position. If this is a problem for you, consider selecting a lower microstep resolution. At 50,000 steps/rev, you would exceed the 16 million step limit after 320 revolutions. At 2000 steps/rev, you can go 8000 revs before exceeding the limit.



Feed to Position

This instruction moves the motor and load from wherever they are to an absolute position. For example, if the load is at the 4 inch position and the program executes a Feed to Position 6 inches, the motor will move two inches clockwise. If the load was at the 10 inch position and you did a Feed to Position 6 inches, the move would be 4 inches counter clockwise.

Feed to Position requires the usual move parameters: speed, accel & decel rates. Like other move instructions, speed can be recalled from an MMI variable, allowing it to be entered by the operator on the MMI panel.

Position can be a positive or negative number, and can be entered on the MMI. Please note that the MMI has no minus (-) key, so you can't enter a negative number on the MMI. You can avoid using negative absolute positions by using the Set Position instruction.

Feed to Position [X]

Move the Motor to an Absolute Position

Position
5.0 inch

☐ Get position from MMI
Name: Dist1

Speed
10.00000 inch/sec

☐ Get speed from MMI
Name: Speed1

Accel 100.0 inch/s/s


Decel 100.0 inch/s/s

OK Cancel



Set Abs Position

This instruction allows you to define the present motor position as any absolute position you like. On some Si™ models, the *Seek Home* instruction automatically clears the absolute position counter when it's finished, defining the home position as 0. But you may want something else. Perhaps you want to think of the home sensor as being the 8 inch position, or 90 degrees, or whatever. Simply put a Set Position instruction after the Seek Home instruction, or anywhere else in your program where you want to define the absolute position.





Save Abs Position

This instruction allows you to save the present absolute position to an MMI variable. This is useful if you want an operator to visually position your load, and then be able to return to that position later in your program.


For a material handling application, you could create a program that uses the Wait Input or Hand Wheel commands to allow the operator to move your load into position. The operator would then press an ENTER button to exit the Wait Input or Hand Wheel instruction. If the next instruction is Save Abs Position, the load position that the operator carefully obtained is recorded in nonvolatile memory. Elsewhere in your program you can use a Feed to Position instruction to return the load there.

Since the Si™ indexers support up to 8 MMI variables, you can save as many as eight different positions.

The sample program “LPdemo” demonstrates the “learning” of two positions.

Even though the positions that the indexer has “learned” will still be remembered the next day (because they are stored in nonvolatile memory), you will need to “home” the system each time it’s powered up. Otherwise, the absolute positions that you’ve saved don’t make any sense.

Note: you need an indexer drive with firmware version 1.52 or later to use the Save Abs Position instruction.





Seek Home

The *Seek Home* instruction allows you to move the motor until a home sensor is found. The home sensor can be wired to any of the general purpose inputs.

Some applications require the motor to start from a certain position each time you turn on the power, but can't guarantee where it was left at the last power down. The solution is to wire a sensor to one of the Si™ Indexer inputs and place a *Seek Home* command at or near the beginning of the program.

The *Seek Home* instruction starts by moving the motor in the direction you have specified. If it finds the sensor, it decelerates to a stop, then backs up to the position where it first detected the sensor. If an end of travel limit is encountered before the home sensor is found, the motor will reverse direction, travel to the opposite end of travel limit, change back to the original direction and resume searching for the sensor.

Seek Home will ask for many of the same parameters as the other feed programs: Speed, accel, decel and direction.

You'll also need to tell the Si™ Indexer which input the sensor is wired to and what input condition to look for. The four input conditions are:

High - move until the specified input reaches a high voltage state. This is the default state of an input if nothing is connected to it.

Low - move until the specified input is at a low voltage state.

Rising Edge - move until the signal goes from low to high. This is similar to the high condition, but the difference is important. If you execute a *Seek Home* command to a high input and the load is already on the home sensor (causing the input to be high) then the load will not move. If you choose "rising edge" instead, the Si™ Indexer will move the load to the edge of the home sensor.

If you need the load to be at the exact same position after each Seek Home command, choose Rising Edge or Falling Edge.

Falling Edge - the opposite of rising edge. Si™ Indexer waits for an input voltage to go high, then low.

You may have noticed a box in the lower right-hand corner of the *Seek Home* dialog box. This tells you how many steps the Si™ Indexer needs to decelerate to a stop. The "Required Clearance" box tells you how much distance you must allow between the limit sensors and any hard stop, based on the speed and decel rate that you've set. If you don't allow enough clearance, the load may crash into something as it decelerates past a limit while seeking home. The higher the speed, the longer it will take to stop. If the decel rate is increased, then the motor can stop in fewer steps.


If you have a BLU-Si or STAC6-Si drive, you will see more input choices, including X0, the encoder index. With Applied Motion motors, X0 reads high when you are on the index and low everywhere else.



Wait Time


This is the simplest instruction. Just enter an amount of time, and the Si™ Indexer will pause for that time before proceeding to the next line in the program. The range is 0.01 to 300 seconds.

What, you want to pause for more than 300 seconds? Did I hear you say 30 minutes? Okay, we can do that. That's the beauty of multiple line programs with a wide range of instructions - you're only limited by your creativity.



You can make the *Wait Time* instruction last longer by placing a repeat loop around it. Now I know we haven't talked about repeat loops yet, so we're going to skip ahead a little here. The first trick is to factor your 3 minute delay into two parts. 30 minutes is 1800 seconds, right? The most we can delay in one *Wait Time* instruction is 300 seconds. Okay, what if we delay for 300 seconds 6 times?

Your program would look like this:



What's the limit? Well, a repeat loop can go 65535 times, so the maximum time you can delay is $65535 \times 300 = 19.66$ million seconds, or 5461 hours. Not long enough? Try two repeat loops, one inside the other. Now we're pausing for up to 40,000 years. Wow!



Wait Input


Rarely does a motion controller operate completely on its own, with no input from the outside world. In most cases, you'll need the Si™ Indexer to wait for something to happen before it goes into motion. The *Wait Input* command is used for that. The *Wait Input* command is also the only instruction that allows you to jog the motor using the JOG CW and JOG CCW inputs.

The *Wait Input* instruction has two modes of operation: single input, where it only looks at one input, and multiple inputs where it can examine up to 8 inputs at once (16 inputs for BLU-Si and STAC6 drives).

In **Single Input** mode, you must specify the input and the voltage condition to expect. The choices are:

High - Wait until the specified input is at a high voltage state. This is the state an input will be in if nothing is connected to it, so be careful if you use this condition. If a wire comes loose, you could end up with undesired motion.

Low - Wait until specified input is at a low voltage state. This happens when the input is conducting current. If you use a momentary contact switch (normally open type), this condition will occur when you press the button.



Rising Edge - Wait until the signal goes from low to high. This is similar to the high condition, but the difference is important. Let's say that your signal into the Si™ drive is one that will go high when you want motion to occur. However, the signal remains high after the motion is complete, going low sometime later. If you choose high as your input condition, the Si™ program will complete the motion and start again because the input signal is still high when it finishes the first move. If you choose rising edge, the Si™ program will wait for the input voltage to go low, then high before moving.

Falling Edge - The opposite of rising edge. Si™ program waits for input voltage to go high, then low.

If you select **Multiple Inputs**, the Wait Input instruction will scan multiple inputs at once to determine if the program should move on to the next instruction. The inputs can be configured as a binary sum (Wait for input 1 low or 3 high) or as a product (Wait for input 1 low *and* 3 high).

If you have a BLU-Si or STAC6 drive, you will see more input choices, including X0, the encoder index. With Applied Motion motors, X0 reads high when you are on the index and low everywhere else.

Multiple Jog Speeds

Drive firmware version 2.08 and later allows you to choose from multiple jog speeds. You can still use the "global" jog speed, as specified on the main screen. You can also select a fixed "local" jog speed that can be unique to each Wait Input instruction. This allows you to build a program with fast (rapid traverse) and slow (creep) jog speeds.

You can also select an MMI variable as the speed. This, in combination with an MMI Speed instruction, allows the operator of your system to enter one or more jog speeds.

Note: the condition **LOW** (or **CLOSED**) occurs when current is flowing through the input terminal. **HIGH** (or **OPEN**) means that no current is flowing.



Hand Wheel


The Hand Wheel instruction is similar to Wait Input. You specify an input and a condition to be met, like “Input 4 low”, and the instruction continues executing until that happens.

The Wait Input instruction allows the user to move the motor using the CW JOG and CCW JOG inputs, or using the MMI arrow keys. Hand Wheel does the same thing, except that it positions the motor as you turn a CNC type hand wheel. The outputs of the hand wheel connect to inputs 1 and 2 of the Si™ indexer. You can specify the “gearing” by telling the Si™ how much motor distance to move each time the hand wheel “clicks” to the next position.

Hand wheels with 100 counts/rev work best. Call the factory for availability of a suitable hand wheel if you are interested in this feature.


You could think of the hand wheel positioning as “digital jogging”: it allows the operator of a machine to achieve very precise adjustment of the load position.

The Hand Wheel is not supported by the Si-100.



Follow Encoder

Follow Hand Wheel Until Input Condition

 Connect Encoder Channel A to Input 1
Connect Encoder Channel B to Input 2

Distance Per Encoder Count
 Steps

Input
☒ 3 ☐ 5 (cw jog) ☐ 7 (cw lim)
☐ 4 ☐ 6 (ccw jog) ☐ 8 (ccw lim)

Condition
☐ High
☒ Low
☐ Rising Edge
☐ Falling Edge


☐ Follow until MMI ENTER
Text to display on MMI

OK
Cancel



Go To

The *Go To* instruction is used to make the indexer-drive jump to another line in the program. At the least, you'll need to have a *Go To* at the end of your program, to jump back to the beginning.



There is only one parameter to enter in a *Go To* instruction: the line number you want to jump to. Click on the spin button to increase or decrease the line number.



Repeat/End Repeat

Repeat

Repeat a Fixed Number of Times

10 Times

☐ Get repeat count from MMI

Name: Count1

☐ Display loop count on MMI line 4

☐ count up ☒ count down

OK Cancel

Sometimes you need to do the same thing several times, and you know in advance how many times that is. Repeat loops allow you to repeat the instructions inside the loop up to 65,535 times.

For example, let's say we are dispensing fluids into an array of containers. There are five rows and five columns of containers, each 100 steps away from the next. Each time we receive a trigger command, we want to move to the next position. After the fifth container is full, we must return to the first, 400 steps back.

The Si™ Indexer that controls the X axis, or motion between columns, would be programmed as follows:

The program begins on line 1. There, we enter the repeat loop. The next four times, the Si™ Indexer will wait for the voltage at Input 1 to fall, then move clockwise


100 steps, taking the dispenser to the next container. After the fourth time, the Si™ Indexer drops out of the loop into line 5. This time when Input 1 falls, the motor is moved 400 steps counterclockwise, returning to the original position.

Sometimes you may need to repeat something more than 65,535 times. Let's say your task is to feed material into a cut off knife, and you want to run 100,000 pieces.

The best solution is to set up 2 loops, one inside the other. The total number of cycles will be the number of repeats in the two loops multiplied together. 100,000 is 10,000 x 10, so we could set one loop for 10 and the other for 10,000.

The *Repeat* instruction can also use data that was gathered and stored by an *MMI Prompt* instruction as the loop count. Just check the box marked "Get repeat count from MMI" and select a variable from the list.

For example, you could put an *MMI*




Prompt in your program to ask for the number of parts to be processed and save that data as Count1. You would then set up the *Repeat* instruction to get the repeat count from the MMI variable Count1.

You can also display the loop count on the MMI as your program runs. You can count up (displaying the num-

ber of parts that have been processed, for example) or you can count down (showing the number of parts remaining.)

When the Repeat instruction displays the loop count on the MMI, it uses line 4. You may want to put an MMI Prompt to “display text only” just before the Repeat instruction telling the operator what the count means, as shown below.

Note: If you use an If Input instruction to exit a Repeat Loop, the loop does not automatically reset the next time you enter it. If you exit a loop by using an If Input instruction, you should use a Reset Repeat Loop instruction to reset the loop. Otherwise, the loop count resumes where it left off.






Reset Loop or Interrupt

Reset Loop Option

Forces a Repeat Loop to reset its counter if it's been terminated by an If Input or Feed to Sensor with Safety Distance instruction.

Sometimes it is necessary to leave a repeat loop before it is completed. Say, for example, you have a repeat loop that is set up to fill 100 bottles with fluid. If the reservoir runs dry, you want to leave the loop. You can do this by putting an If Input instruction inside the loop, triggered by a fluid sensor. The If Input would branch outside the loop, perhaps to an MMI Prompt telling the machine operator to refill the reservoir.

Now suppose that 60 bottles have been filled, with 40 remaining. If you want the loop to “pick up where it left off”, then simply branch back to the beginning of the loop (to the Repeat instruction) after the operator finishes




refilling, and the loop will automatically fill the remaining 40 bottles.

On the other hand, what if you are drilling holes in parts, and each part gets five holes. The motor is used to advance the part by 1 inch for each hole. So, you have a repeat loop with a count of 5. Along comes a bad part, detected after the 3rd hole is drilled. You exit the loop with 2 counts remaining.

If you simply reenter the loop again, the next part will only get two holes drilled into it. What you really want is for the loop to reset itself. For this, you must use the Reset Repeat Loop instruction, as shown above.


Reset Interrupt Option

This option is used for re-enabling an interrupt as you exit your interrupt handling routine. It is only used for a Go To type interrupt. For a Call/Return interrupt, use the Return from Interrupt instruction to re-enable.





Set Output



Earlier, we discussed the *Wait Input* instruction as a way to make the Si™ Indexer wait for external events to happen before proceeding with the program. Sometimes you want the opposite: the Si™ Indexer should tell other equipment when to proceed. The *Set Output* command lets you pick one of the three outputs (seven on a BLU-Si drive) and put a voltage signal on it. For a detailed description of the circuitry and connections, see the section “Wiring Inputs and Outputs” in your hardware manual.

There are four choices of output conditions:


High - Makes the photo transistor open. In circuits where the “-” output pin is grounded, and the “+” pin is pulled up, this causes a high voltage to appear on the “+” pin.

Low - Makes the photo transistor close. In circuits where the “-” output pin is grounded, this causes a low voltage to appear on the “+” pin.

High Pulse - Makes the photo transistor open for a specified amount of time (2 to 500 milliseconds)

Low Pulse - Makes the photo transistor close for a specified amount of time (2 to 500 milliseconds)


At power-up, the Si™ Indexer sets all 3 programmable outputs high (open circuit).



For an example of using the *Set Output* instruction in your program, let's consider the example of filling containers. Each time the Si™ Indexer moves to a new position, it should tell the dispenser that it's arrived. We'll do this with a low pulse, but your choice would depend on the kind of signal the dispenser wants to see in order to be activated.

After adding a *Set Output* instruction after each *Feed to Length*, we have the program shown on the left.


There may be occasions where you want a long pulse. This can be done by combining two *Set Output* commands with a *Wait Time*. The instructions shown below will produce a high pulse of 5 seconds on Output 3.





If Input Go To

This instruction allows the Si™ Indexer to make decisions based on input signals. You can choose “Single Input” or “Multiple Inputs.”




You'll need to choose an input terminal for the instruction to check. You also need to tell the indexer what signal condition to look for. Finally, you must set the line number that the instruction will jump to if the input condition occurs.

We included the *If Input* instruction for three reasons.


1) It allows you to skip part of your program based on an external condition. For example, let's say you are building a machine and the Si™ indexer's task is to feed parts. Normally the indexer waits only a half second before feeding the next part, because that's how long it takes for your saw to cut the part. But sometimes you process parts of a different material that takes longer to cut (aluminum vs. steel, maybe). On the days you run steel

parts, you'd like to be able to flip a switch and change the delay between parts to 1.5 seconds. This is how you do it:




The program feeds a part during line 4. Line 5 makes it wait a half second. If the switch, which you've connected to Input 1, is closed (low voltage signal state) then the program jumps to Step 8, skipping the extra 1 second of delay. If the switch is open, the delay occurs. You could then mark your switch's open circuit position as “Steel” and the closed position as “Aluminum”.

2) The second reason for including the *If Input* instruction is to allow you to change a parameter such as distance or speed based on an input. Consider that last example. How will the cutoff saw know how fast to go when I set the switch for “Aluminum” or “Steel?” Well, we could wire the switch that controls the movement of the saw to one of the general purpose inputs. This time we write the program as shown below.



When the indexer gets to Step 4, it will look at the “Steel/Aluminum” switch. If the signal is low (Aluminum) it jumps to the Feed to Length program at Step 7, which moves the saw at 3 revolutions per second. If the switch is high, the program does not jump, but instead executes the *Feed to Length* at Step 5, which feeds at 1.0 rev/sec. Then, the Si™ Indexer jumps past the second Feed because of the Go To instruction in Step 5. (Don't forget the *Go To* or you could end up moving the saw twice.)

3) The final reason we've given you the power of *If Input* is so you can have multiple programs within your 100 line program space. Perhaps what you want your system to do is two completely different things depending on an input. Let's say that each of these tasks requires 4 instructions. This is what you do:



Depending on the state of Input 2, the program will either execute lines 4 - 9 or lines 11 - 15. Either way, the program ultimately returns to line 3 to check the condition of the switch again.

If you select "Multiple Inputs" then you can combine multiple inputs in a logical "or" or "and" expression. For example: "If input 2 low or 3 low or 4 high goto line x".

If you have a BLU-Si drive, you will see more input choices, including X0, the encoder index. With Applied Motion motors, X0 reads high when you are on the index and low everywhere else.

Note: If you use an If Input instruction to exit a Repeat Loop, the loop does not automatically reset the next time you enter it. If you exit a loop by using an If Input instruction, you should use a Reset Repeat Loop instruction to reset the loop. Otherwise, the loop count resumes where it left off.



Call and Return

Call and Return instructions are used to create and use subroutines. Subroutines are useful programming tools for two reasons. First, if there is set of instructions that appear in your program more than once, you can save program lines by creating a subroutine and calling it from each place the repeated program lines occur. For example, you may have a “handshaking” routine at the end of each move. You could put the handshaking routines near the end of your program, followed by a Return instruction. Then you just Call that subroutine after each move. That frees up program lines so that you can do more.



Subroutines can also help you avoid programming mistakes. If you have the same sequence of instruction at more than one place in your program, and you decide to change one of the instructions, you must remember to change all occurrences of that instruction in your program. If the sequence is in a subroutine, you only need to change it in one place.

Example: Suppose that you are feeding parts and then cutting them. After each move you must signal another device to perform the cut, then wait for it to be done. A typical sequence would be:

Set Output (to tell the another drive to make the cutting move)
Wait Time (to give the other device time to respond to the Set Output)
Wait Input (wait for other device to signal completion)

To make this a subroutine, just place the three lines near the end of your program (line 90, for example) and add a Return from Subroutine instruction. Each time you make a move in your program, add a Call Line 90 instruction.

When you program the Return instruction, be sure to choose the “from Subroutine” option.




Call Stack

Each time you call a subroutine, the drive must make note of where you came from, so that the subroutine's Return instruction knows where to go. We store this “return address” on the Call Stack. If you call a subroutine and it calls another subroutine, another value will be pushed onto the stack. This process cannot continue forever, as the call stack is just five levels deep.

If you call a sub that calls a sub that calls another sub, you're okay. But don't allow more than five calls without a return. If you are using interrupts, then you must save one stack level for that, as the interrupt uses one stack level.

Animation

When you are in development mode (drive still being controlled by the Si Programmer application on your PC) we animate the call stack in the status window. This will give you a feel for how the stack works and whether you're getting close to a stack overflow.






Change Current

Motor current is normally set on the main screen of the *Si Programmer™* and applies to all program instructions. But what if you want to change the current on command? For example, you may want to temporarily turn off the motor current while the operator makes manual adjustments to a mechanism, or loads a new roll of labels. Overcoming the holding torque of a step motor by hand can be difficult, so it's sometimes best to shut off the current completely.

In other cases, you may want to temporarily increase the motor current to achieve more torque, but are unable to leave it that way all the time without overheating.

The Change Current instruction allows you to turn off the current, to resume the normal current setting, or to specify a new current setting.





Change Servo

This instruction is only available if you are using a BLU-Si or SV7-Si servo drive.

The Change Servo instruction allows you to change the six control loop gains and the continuous and peak current settings. You can also turn the servo loop on or off.

Normally, you will use the *Quick Tuner* software to configure and tune your drive. However, if you have a changing load you may need to change some or all of the tuning parameters between moves. For example, if you are transporting objects on a linear slide and the mass greatly changes when an object is placed on the slide, you will get better performance if you adjust the gains between moves. In particular, you might want to increase KAFF, the acceleration feed forward, to compensate for increased load inertia.

Before entering values into the Change Servo instruction, you should try these values in *Quick Tuner*. That way you can measure and observe the performance.

Changing the current will affect the motor torque.

Turning the servo off is useful if you want the motor to spin freely.

Change Control Loop Tuning

Parameter	Value	Group
<input type="checkbox"/> Proportional Gain	5000	Stiffness
<input type="checkbox"/> Integral Gain	5000	
<input type="checkbox"/> Derivative Gain	2000	Damping
<input type="checkbox"/> Velocity Feedback	4000	
<input type="checkbox"/> Velocity Feedfwd	4000	
<input checked="" type="checkbox"/> Accel Feedforward	84	Inertia
<input type="checkbox"/> Continuous Current	1	Arms
<input type="checkbox"/> Peak Current	2	

Warning: do not enter values into this instruction without first testing them with Quick Tuner to verify that the motor and load behave as intended.

☒ Servo On ☐ Servo Off **OK** **Cancel**



Comment


The Comment lets you leave notes in your program. That way if someone else needs to modify your program in the future they'll understand what you've done. The comments can also help you organize the program for yourself.

Whether you save your program to disk or just download it to the drive, the comments stay with it. They do not affect the way your program runs: when the Si™ Indexer executes a program, it skips over the comments.

We suggest that you place a comment on the first line of your program to let future programmers know who wrote the program, when it was written, and what it does. You can also put in comments at other places in your program. Perhaps just before a Feed to Length move, you would want to add the comment "Rotate the part 1/4 turn."

A little time spent now commenting your program might save you a great deal more time later on, when you've forgotten that "Feed to Length 3000 Steps" means "Rotate the part 1/4 turn."

There is a limit to the number of comments your program can have. The Si™ Indexer has a "string pool" of 400 characters. All *MMI Prompts* text goes into the string pool, as any *Comment* instructions whose strings exceed 12 characters.



Command Buttons

Download, Upload & Execute

The Si™ Indexer was designed to operate without a host computer once your program is finished and tested. At first, though, you'll probably find yourself running it from the PC much of the time. That way you can quickly make changes in your program to fix errors or conduct experiments.

The *Si Programmer*™ software provides four command buttons for interacting with the indexer-drive.

Download transfers the program from the Windows software to the Si™ Indexer that's plugged into your serial port. The transfer takes about 3 seconds. You must download the program before you can execute it.

Note: *when downloading to the indexer/drive, make sure the JOG inputs are not activated. If in doubt, remove the JOG CW and JOG CCW connector plug.*

Upload lets you extract whatever program is in the Si™ Indexer memory and display it on the screen. If you want to modify a program already in your Si™ Indexer, you can use the Upload command to bring it back to the PC.

Execute tells the Si™ Indexer to begin running the program that is in its internal memory, starting on line 1. After hitting the Execute button, you'll see a box appear with a status display and five program control buttons. (Unless your indexer/drive has firmware prior to 1.40, in which case you'll see a much simpler execute box. Older drives are not able to send real time status information to the PC, and cannot respond to advanced commands like Pause and Single Step.)

If the drive is not connected to the PC or the *Si Programmer*™ software is not running, the drive will execute the most recently downloaded program, starting on line 1.


Execute Panel Commands: Stop, Run, Pause, Step and Reset

Pressing **STOP** will interrupt the indexer-drive at any point in the program and close the execute panel. You will find this feature useful when the drive starts doing things you didn't intend for it to do.

Pause halts the program, but does not close the execute box. While the program is paused, the display of inputs is continuously updated, so you can adjust sensors and switches and see the result in real time. *(If you have drive firmware 2.22 or later and Si Programmer 2.5.13 or later, the I/O status is real time even when the program is not paused.)*

Step executes the next line of the program, then automatically pauses it again. The drive must be paused for the Step button to work.


Pressing **Run** makes the program run again, from where you paused it. **Reset**



sends program execution back to line 1.

If you have drive firmware 2.22 or later and Si Programmer 2.5.13 or later, the I/O status is real time when your program is running and when it is paused.

The STAC6-Si, ST5/10-Si, SV7-Si, BLuAC5-Si and BLuDC-Si drives with firmware 2.22 or later provide a real time view of the drive's status flags, as shown below. You can also monitor one internal variable of your choice, including motor position, encoder position, position error, motor speed, current, drive temperature, supply voltage and alarm code. This feature requires *Si Programmer 2.5.13* or later.



Save, Open, Print & Quit

In addition to exchanging programs with the Si™ Indexer, the programming software can also save & load programs using your hard drive, and can print hard copies of programs using your printer.

The **Save** button lets you save a program to the hard drive. A file dialog box will ask you to pick a name for the program. You can enter up to 8 characters, not including the suffix “.SI5”. If you don’t enter a suffix, the software will add “.SI5” to your file name automatically. If you type a different suffix, it will automatically change to “.SI5”. The characters in the filename must conform to the usual DOS/Windows 3.1 rules. The safest approach is to use only letters and numbers in your filename, and to avoid special characters like “?” or “\”.



The **Open** button provides you with a dialog box showing all the “.SI5” files on your drive. Click to select one, then click OK to load it.

Several example programs are installed with your programming software. It’s a good idea to load some of the examples and look at them: they may help you with your own application.

Print lets you make a hard copy of your program on any printer that’s attached to your computer and installed in Windows. Print uses the standard Windows printer dialog, allowing you to specify which printer to use if you have more than one.

If you call for help, we may ask you to print your program and fax it to us. If you have a fax modem that acts as a printer, you can use it to fax the program directly to us from the programming software. You’ll have to enter our fax number at some point, which is (831) 761-6544.

The **Quit** button exits the *Si Programmer™*.

Encoder Feedback: 3540i with Encoder Option Board

Most step motor applications run “open loop,” where a motor position is commanded and the controller assumes that the motor obeyed. If the system is designed with a reasonable amount of torque margin, and nothing blocks the motor’s path, this works perfectly.

However, some applications require feedback from an encoder to verify that the commanded move has been executed correctly. For example, if you are processing very expensive parts, it’s worth spending a little extra money on your motion control hardware so that you don’t destroy the parts if something goes wrong. In other cases, it is desirable to get more accurate positioning by using encoder feedback to compensate for slight errors in the motor position and load linkage.

To support such applications, the 3540i drive can accept quadrature encoder input with the help of the 1000-175 encoder option board. We can also provide a motor with an encoder mounted on the back.

If you select the 3540i drive and then open the “steps/rev” dialog, you can tell the *Si Programmer* software what kind of encoder you have and what to do about any errors that occur.


The first thing you should do is enter the counts/rev of the encoder. Many encoders are specified in “lines”. Since the *Si*™ drives use X4 quadrature decoding, the counts/rev will always be 4 times the number of lines. For example, the popular U.S. Digital model E2-1000-250-H encoder has 1000 lines, so you would enter 4000 counts.

You can use any encoder you want as long as your selection of motor steps/rev is evenly divisible by the counts/rev. In the dialog on the left, the system is set for 20,000 steps/rev and 4000 counts/rev. $20,000 / 4000 = 5$, a whole number, so this combination is okay. You could also have selected 36,000 steps/rev with this encoder, but not 12,800.

Next, enter the maximum amount of position error your application can tolerate. We used 10 encoder counts, which is .0025 inches in our

example. If, after a Feed to Length, Feed and Return or Feed to Position instruction, the error exceeds .0025 inches, the controller will automatically try to correct it by making a series of short moves. The controller also performs “static position maintenance” during Wait Input and MMI Prompt instructions. Static position maintenance corrects for external forces that push the motor out of position when it’s supposed to be standing still. In the case of a total obstruction or insurmountable force, it may be impossible to correct the error. In that case, you can have the controller “give up” and branch to another part of your program. That way, you can have an “error recovery” routine. The picture on the next page shows a simple example of an error recovery routine.

We chose line 10 as the encoder error branch line by entering it in the steps/rev dialog. The error recovery line is automatically shown in light blue so that it's easy to identify when looking at your program. (If you have the printed version of this manual, it probably looks gray.)



In our example, if a position error occurs, the controller tries to correct it up to 20 times, then gives up and jumps to line 10. On line 10, we have an MMI Prompt telling the operator to fix the problem.

Corrective move speed and acceleration rate

For firmware version 2.08 and later, you can specify the speed and acceleration rate to be used by the corrective move in the microstep/encoder dialog. These values are not used by older firmware versions - those drives will use the same

speed and acceleration rate as the move that failed.

Once the error branch takes place, the autocorrection process is turned off until you branch again by using a Go To or If Input instruction. Thus, the controller will stop trying to make corrective moves while in your error recovery routine, and will automatically resume once you've fixed the problem and jumped back.

If you have a 3540i drive and you aren't using an encoder, select the option "Ignore the error." That will turn off the autocorrection and error branching. If you are using the encoder, select "Correct the error".



Notes:

1. We do not recommend the use of "0% idle current reduction" if you are using encoder feedback.
2. To use the encoder feedback feature, you must have Si Programmer™ software version 1.75 or later and drive firmware version 1.75 or later.
3. For additional information, please see instructions for P/N 1000-175 Encoder & RS485 Option Board.

Encoder Feedback: STAC6 & ST5/10

The optional encoder connects to the drive using an HD15 male connector. You'll have to add this connector yourself according to the diagram below. It is not essential to connect the Z (index) channel.

If you are using an encoder with single ended outputs, shame on you. Differential connections are far less sensitive to electrical interference and life is too short to waste time deciphering the bizarre problems that can occur with a poor quality encoder. That said, single ended encoders should be connected to the A+ and B+ terminals. Leave A- and B- unconnected. They are internally biased to the proper voltage for best results. You'll also need to select the "single ended" box in the encoder dialog or the drive will think you have a broken encoder wire. That's another good reason to use a differential encoder: the drive can detect a broken wire or bad signal and alert you to the problem.



Encoder Feedback Options


Stall Detection continuously compares the actual motor position, as reported by the encoder, against the theoretical motor position. If the motor strays so far out of position that it can produce no torque, a position fault occurs. This includes a motor at rest being driven out of position by an external force. Check the box below Stall Detection if you want the drive to fault when the motor stalls. This fault can be reported by the Fault output and cleared by the Alarm Reset input (see I/O Dialog).

Stall Prevention can prevent many stalls before they occur. The drive achieves this by using the encoder to monitor the lead angle of the motor, a measure of torque utilization. If the motion profile begins to demand more torque than the motor can produce, the velocity is automatically reduced before the motor stalls. To engage stall prevention, simply check the Stall Prevention box and enter the maximum torque utilization you want to allow.

In the event that the motor cannot move at all, such as hitting a hard stop, you may want to fault the drive after a given amount of time by checking the Hard Stop box and entering a time limit.

Branch on Stall allows you to handle a stalled motor in your program. Typically you would take some kind of action such as alerting an operator via the MMI or setting an output to signal the fault to another piece of equipment. Once the condition has been handled, you'll need to clear the fault and reenergize the motor with a *Change Current* instruction (choose the "resume normal current" option). The next time your program branches with a *Go To* or *If Input* instruction, the encoder functionality is restored.

For Stall Prevention and Stall Detection to work reliably, the motor shaft must not be disturbed when the drive is powered on or it will not be able to establish a known rotor position. The minimum recommended encoder resolution is 4000 counts/turn (1000 lines).



The dialog box titled "Encoder Feedback (optional)" contains the following settings:

- Encoder:**
 - Resolution: 4000 counts/turn (1000 lines)
 - Ch A leads Ch B when shaft turns: ☒ cw ☐ ccw
 - ☐ Single Ended (not recommended)
 - Timing diagram: A square wave diagram showing Ch A (purple) and Ch B (orange) signals. Ch A is high when Ch B is low, and vice versa. The diagram is labeled "shaft turning ccw".
- Stall Detection:**
 - ☐ Fault drive if motor stalls (or is forced out of position)
- Stall Prevention:**
 - ☒ Automatically adjust torque utilization to prevent stalling. Use 100 % max
 - ☒ Hard stop: fault drive if motor stalls for more than 20 msec
- Branch on Stall:**
 - ☒ If motor stalls, branch to line 15

Buttons at the bottom: Help, Cancel, OK.

Servo Tuning & Motor Set Up

If you are programming an SV or BLU servo drive, you can configure and tune the servo system from *Si Programmer*. Once you've chosen the correct drive model from the drop-down list, the Alarms, Tuning and Motor buttons will appear on the left side of the main screen, providing access to special windows that enable you to properly set up the special features of your servo drive. If you are working with a BLuAC drive, you'll also see a Regen button.



Alarms Dialog

From this window you can view the alarm history of your drive, clear the history, or clear an active alarm. You can also set the position error limit and set up an error recovery branch in case a fault occurs during your program.

Alarm History
✕

	1	2	3	4	5	6	7	8
Position Error								
CCW Limit								
CW Limit								
Drive Overtemp								
Internal Voltage								
Over Voltage								
Under Voltage								
Motor Short								
Bad Hall Sensor								
Bad Encoder								
Communication								
Flash Memory								
Timing Wiz Failed								
Current Foldback								
Blank Q Segment								
Move when disabled								

OK

Cancel

Help

Clear Alarm

Clear History

indicates an alarm. Code 1 is the most recent.

Drive Fault

If the drive faults:

☒ stop motion, halt program
☐ stop motion, branch to line 1

☒ close fault output (Y3)
☐ open fault output (Y3)
☐ neither

Positioning Error Fault: ± 2000 counts


Regen Dialog

If you rapidly decelerate a load from a high speed, much of the kinetic energy of that load is transferred back to the power supply. This can trip the overvoltage protection of the power supply, causing it to shut down. For the BLuDC and SV series DC powered drives, we recommend the addition of one RC050 regeneration clamp for each power supply. The BLuAC5 drives have built-in regen clamps.

Due to the extended power range of the BLUAC5 drive, the built-in regen clamp may not be enough in all cases. If you experience regen faults while operating your drive, you should first check to see that the internal regen resistor is actually connected. On the bottom of the drive, you should see a jumper wire connecting the outer two terminals of the regen connector, as shown below. If the wire or connector are missing, remove power from the drive and replace them.

If the internal resistor is connected and you still experience regen faults on your BLU-AC, you'll need to connect a larger resistor externally. You also must inform the drive that you've done this, by selecting the "external" option button. Then you must enter the continuous power capacity, in watts, and the resistance. Now for the hard part: entering the number of seconds that the peak regen power level can be sustained by your external resistor. The peak regen power is $160,000 / R$ where R is the resistance of your external resistor. For a 50 ohm resistor, the peak power is 3200 watts. The resistor manufacturer can help you with this.

Consult the hardware manual when connecting the external resistor to the drive.



The Motor/Encoder Dialog

This window is for configuring the motor feedback (encoder and commutation settings), setting the current and if necessary invoking the Timing Wizard or Current Loop Tuning functions.

Encoder and Hall Timing

If you are using an Applied Motion Products' Alpha, N or M series motor, the factory drive settings are correct for this type of motor. You do not need to enter the encoder resolution or run the Timing Wizard. You can skip this section. For V and 6020 series motors, you must run the Wizard.

Three phase brushless DC motors provide three signals that tell the drive when to switch from one phase combination to another. These are called commutation or Hall signals. The relationship of the commutation signals to the motor phases (called "Hall timing") is not the same for all manufacturers. That's okay, because Applied Motion drives can accept motors with nearly any hall timing.

A few motors have unequally spaced Hall signals. These are sometimes called 60° motors. (Evenly spaced hall waveforms are 120° apart.) The one type of motor you cannot use is one with 60 degree



timing. Unless its Hall outputs are differential, in which case you can convert it to 120° by swapping the “-” and “+” outputs of Hall 2. If you have a 60° motor with single ended Hall outputs, you cannot use that motor.

To set the hall timing, you must first wire your system. That includes connecting the motor to the drive and the drive to a power source. Refer to the hardware manual for your drive when making these connections. Once you have connected the motor to the drive, we can configure the timing using the *Quick Tuner*.

If you are using a motor from another manufacturer, try the Hall Timing Wizard first. In most cases, it can automatically detect your motor timing pattern and configure the *Quick Tuner* software for it. You may also manually configure your motor by skipping ahead to the section “Manual Configuration.”

Hall timing varies among motor manufacturers. The timing diagrams supplied with motors (when they are supplied) differ in their format, too, complicating the task of configuring a motor for the first time. To ease this burden, the *Si Programmer™* includes a Hall Timing Wizard that automatically detects the necessary configuration for your motor. To use the Timing Wizard, you must do the following:

Note:- When using BLu servo drives the encoder resolution and the number of poles must be entered before the following procedure is attempted.


1. Connect the motor to the drive. Wire the phases, hall and encoder signals “straight across” as detailed in your drive’s Hardware Manual.
2. Do not connect any load to the motor. It is important that the motor be unloaded and completely free to move during the operation of the Hall Timing Wizard.

3. Connect the programming cable to your PC.
4. Launch the *Si Programmer™* software.
5. Connect and apply power to the drive.
6. Click the “Motor” button, then click on the “Timing Wizard” button.
7. The Wizard will remind you to disconnect the motor from any load.
8. The Wizard will ask you to rotate the motor shaft in the clockwise direction. The Wizard will tell you when to stop turning the shaft.
9. Click OK and the Wizard will do the rest. If successful, the Wizard will determine the timing and apply those settings to the drive set up. **You also will need to tune the drive - we don't have a wizard for that.**

If the Hall Timing Wizard fails, you might still be able to configure the system manually. But some motors cannot be used with the BLu drives.

The Tuning Dialog

This window allows you to set the control loop parameters (also called servo gains) and adjust the filters. You can also experiment with the response to your choices of gains and filter settings using a built-in digital scope.



The Scope

At some point, you are going to want to observe how well your choice of gain parameters works. We have included a sampling oscilloscope feature for this reason. All you have to do is select the move profile you'd like to try, by entering a move distance, a maximum speed, and the acceleration rate. You should select a move that

is meaningful to your application. There is no point in optimizing your speed around 50 rev/sec if your application only calls for speeds of 10 rps. The same is true for distance and acceleration.

The oscilloscope window can display either one or two measurements at a time. The choices include Actual Speed, Target Speed, Position Error, Current Command and Actual Position. The drive only samples what you have selected, so if you change plot parameters you must sample again to update the display. By making the oscilloscope “full screen” you can get a better display resolution and see your move in more detail.

You may also choose clockwise or counterclockwise rotation. If your load is vertical, you may want to observe the differences. If your load is linear, then you can't keep sampling in the same direction or you'll run out of travel. For applications where travel is limited, choose “alternate direction.” Then the drive will change the direction after each move.

If you have selected “Sample Once”, you will get one sample move, and one graph each time you click on “Start.”

The scope automatically scales the graph to fit the data. If you are tuning your drive to minimize position error, you may find it hard to tell “at a glance” that the error has changed because the graphs keep re-scaling to fit the entire scope area. If uncheck the “Auto Scale” box, the graph vertical axes will no longer change and it will be easier to judge the response to changes you've made in the tuning parameters. If the trace becomes too large to fit or too small to see in detail, you can click on the “Now” button to perform a onetime re-scaling of the data.

If you don't like the colors we've chosen for the two traces or the grid or background, you can change them by clicking on the color buttons. Don't worry, we won't be offended. If you have enlarged the scope by dragging the border of the Tuner window or clicking the maximize button, you might want to check “Thick Lines”.

Sometimes it is convenient to keep the sampling process running automatically while you adjust the gain parameter slide bars. To do this, select “Sample Continuously.” The drive will start sampling and plotting when you click on “Start” and will not stop until you click “Stop.” (Note: the Start button becomes a Stop button when you click it in Continuous sample mode.)

It is not necessary to click on the Download button when sampling. If the *Si Programmer™* detects any changes in the drive settings, it will automatically download the new settings before each sample move.

Each time the settings are downloaded to the drive, they are written into the nonvolatile memory, and will still be there the next time you power up the drive.

Control Loop Tuning

Like most modern servo drives, ours employ sophisticated algorithms and electronics for controlling the torque, velocity and position of the motor and load.

Sensors are used to tell the drive what the motor is doing. That way, the drive can continuously alter the voltage and current applied to the motor until the motor does what you want. This is called “closed loop control.”

One of the loops controls the amount of current in the motor. This circuit requires no adjustment other than specifying the maximum current the motor can handle without overheating.

On the BLU and SV servo drives the position control loop is a Proportional-Integral-Derivative (PID) type. This type of closed loop control is used widely, not just in motion control but also in other process controls. We chose PID control for our drives because it is easy to understand, which makes it easier for you to set up our drives for your application.

The PID loop compares the intended motor position to the actual motor position as reported by the encoder. The difference is called error, and the PID loop acts on this error in three ways: the Proportional term, the Inte-

gral term and the Derivative.

The BLu and SV series drives add three additional gain terms to enable greater system control: velocity feedback, velocity feedforward and acceleration feedforward. That's a total of six gain parameters, which can be a little intimidating for a first time user. The Simple tab combines the six parameters in just three: Stiffness, Damping and Inertia. For advanced users, you can click on the Advanced tab and access all six gains separately.

Stiffness Gain Terms

P: The Proportional Term

The simplest part of the PID loop is the proportional, or P, term. The drive applies current to the motor in direct proportion to the error. Here's an example: if the motor were standing still, and you suddenly turned the shaft by hand, you'd want the drive to increase the motor current so that it goes back into position.

The farther you disturb the motor from its target position, the more the torque will increase. The P term (also called P gain) governs how much torque you get for a given amount of error U_n . In general, if you have more load inertia, you'll need more torque and therefore a higher P gain.

The torque provided by the P term is $T = K_p U_n$.

I: The Integral

If you think about the previous example for a moment, you may realize that P alone will not give you perfect position. If you applied one ounce-inch of torque to the motor, it would move out of position. The P term will increase the motor torque until it is producing as much torque as you are. Then the motor stops moving. But there is still error. The I term adds up all the error that the drive has seen and produces a torque that is added to the torque command from the P term:

$$T = K_p U_n + K_i \Sigma(U).$$


In our example, the P term allowed the motor to reach equilibrium at a position where the applied torque from your hand equaled the torque of the P term. Thus, the error was not zero. But the I term will keep adding up that error and continue to increase the torque until the motor truly returns to the target position.

Damping Gain Terms

D: The Derivative

So far, we've just talked about a motor that is disturbed when standing still. But the objective of motion control is to get that motor moving on its own. The problem with electric motors is that they tend to be very "springy", a condition known as "underdamped". If you tried to run a motor with a pure PI controller the motor would over-respond to small errors, creating ever larger errors, ultimately becoming unstable. If you knew what the motor was going to do before it did it, you could prevent this. For those of you who studied calculus, you may recall that you can predict what something is going to do by its rate of change, or derivative.

If you are driving your car into your garage, do you wait until you are fully in the garage before hitting the brakes? That would be a bad idea for you, your car, and the back wall of the garage. Instead, most people slow down as they see the distance between them and their objective get smaller.




A motor drive can control a motor better if it examines the rate of change of the position error and includes that in its torque calculation. For example, if the motor has error, but the error is decreasing, back off on the torque. That's what the "D" term does.

Vfb: Velocity Feedback

As motor power per size has gone up so has the size of the loads. As more performance is asked of the servo motor we may need to add more damping. Velocity feedback has been added to the BLU servo drive to provide greater damping for the larger loads.

This term adds in the motor actual Velocity as negative feedback and usually works in conjunction with the velocity feedforward term (see below). If the velocity of the motor matches what is expected no feedback value is generated. If however the velocities do not match the negative feedback helps to "damp" the differences in velocity. Typically both terms are set to the same value.



Vff: Velocity Feedforward

The velocity feedforward term works with the velocity feedback term to add more damping capability to the servo algorithm. The feed forward value is generated by the "Trajectory Calculation" algorithm. This setting is useful for minimizing position error while in motion by automatically providing needed torque to drive the load rather than waiting for position error to build up and then compensating. Applications which require the load position to be accurate throughout the move, such as CNC machining, benefit from velocity feedforward.

Inertia Gain Term: Acceleration Feedforward


By anticipating the torque needed to accelerate a load, the BLU servo can handle higher inertial loads and provide better positional accuracy during the accel/decel segments of a move. The acceleration feedforward term does this by adding an acceleration value to the control value. The acceleration value is derived from the Trajectory Calculation during the acceleration and deceleration phase. It should be set in direct proportion to the load inertia. The position error display of the scope can help you correctly set the acceleration feedforward.

Filters


The SV and BLU servos provide control loop filters for special situations. The most commonly used is the PID Output Filter. If your system is subject to mechanical resonance, you should set this low pass filter below the natural frequency of your system so that the PID output does not excite the resonance.

If you have a large inertial load, you'll probably find that you need to set the gain parameters high, especially P and I, to get good response. Then you will want to increase the damping to prevent ringing. Now the system is likely to be so tight that if you have a springy, all metal coupling it may "buzz" or "squawk." Reducing the frequency of the velocity feedback and derivative filters can remove this objectionable sound.

The Jerk filter transforms the traditional "trapezoidal" velocity profile into an S-curve by limiting jerk, the rate of change of acceleration. This feature is useful for any application where a smooth transition into and out of acceleration is needed. Fluid handling applications benefit from S-curves and their use



also reduces mechanical wear and tear. Elevators use S-curves to provide a smooth ride for the passengers. If you've ever been on an elevator with the control system that was not functioning correctly, you probably understand the term "jerk".



Menu Options

Drive...Restore Factory Defaults

If things really get out of hand, you can click this button to return the drive to the way it was when we shipped it from the factory.

Drive...Position Error Limit

Positioning error is the difference, in encoder counts, between the actual position and the commanded position of the motor. A small amount of positioning error is a normal part of a servo system. But sometimes the unexpected can happen. A wire might break, a sensor could fail or the motor may encounter a physical obstruction. You might even one day forget to set up and tune a drive before installing it into a system. In all of these cases, you'll want to know that something is wrong as soon as possible and without damaging anything. For this reason, the SV and BLu drives include a position error fault limit. Anytime the position error (as reported by the encoder) exceeds this limit, the drive cuts power to the motor and enters fault mode. (See the *Servo Faults* section for details.)

You can set the fault limit to as little as 10 encoder counts, or as much as 32000. When you're first tuning the system, you should set this value high so that the drive doesn't shut down as you experiment with tuning parameters. Once the drive is properly tuned and you know how much error to expect during normal operation, you can set an appropriate fault limit. For example: set the Tuner's scope to plot position error. Execute some aggressive sample moves, using the maximum speed and acceleration that you plan to use in your application. If the maximum position error is, say, 50 counts, then you could safely set the fault limit at 100.

You can also set the position error limit from the Alarm dialog.


Tools...Monitor

One of the buttons near the top of the Quick Tuner screen is labelled Monitor. If you are using a BLu servo drive, you can click on it to reveal the Monitor panel. Designed to assist with commissioning and fault finding this configurable screen will display all the condition of all the I/O and drive status outputs.

The monitor also features three configurable displays that can show live information about the drive. Each can be configured to display one of the following parameters.

- Position Error
- Target Speed
- Actual Current
- Drive Temp
- Alarm Code
- Actual Speed
- Command Current
- Supply Voltage
- Encoder Count
- Ain Voltage

Note: By clicking on the Encoder Count, you can return the value to zero.



Servo Tuning Tutorial

Blu and SV servo drives have the same “PID” control parameters as most other servo drives plus a few more. As motor power per unit size has increased so have the load requirements for servo motors. The basic PID controller is great for loads that are not greater than 5:1 inertial mismatch (the ratio of load to motor inertia). To handle the increased demands of high inertial loads, three more control parameters are included: velocity feedback (KVf), velocity feedforward (KVff) and acceleration feedforward (KAff). You could say we have a “PID-VFA” servo control algorithm.

To simplify the tuning process, we have grouped the six parameters together into three main functions:

1. Stiffness - KP & KI; these parameters work primarily to maintain the servo position with minimal error throughout the move profile.
2. Damping - KD, KVf & KVff; these work to minimize oscillation and overshoot in the motion profile. KD works mainly on the higher frequency oscillations while the other two work at lower frequencies, especially with high inertia loads.
3. Inertia - KAff; this parameter is specifically used to counter the affects of large inertial loads during acceleration and deceleration.

You can adjust the servo parameters in groups or, on the “Advanced” tab, individually. When tuning the servo we can start with just the “KP” and “KD” terms.

When you installed *Si Programmer™*, the installer provided some files that contain a good starting point for tuning the servo drive with our A, N, M and V series motors. We have expanded the range of inertias and now have files for each motor that cover inertias of 1:1, 5:1 and 10:1.

Getting Ready for Tuning

Before you begin, it's good to do some homework on the load that the motor will drive. The two primary load issues are the “frictional” and “inertial” torque requirements. In a servo system “frictional torque” is the easiest to handle, so be sure to measure, calculate, or estimate the inertial torque. Knowing this requirement will help you understand how much gain is needed in some of the tuning parameters. Calculating or estimating the inertial load will result in a number in units such as “g-cm²” or “oz-in-sec²”. These are good units to use because AMP servo motors are rated using them. For AMP servo motor specifications, refer to the product catalog or visit our web-site.

With a good estimate of the inertial load and knowing the inertia of the motor you are using, you can now select the file that best represents your load. You will need to do a little more math to come up with an inertia ratio. The file names list the motor first, then the load. The files are available typically in 1:1, 5:1 and 10:1 ratios. Select the nearest one and open it.

We need to give the drive a little more information before we test the servo system. The seemingly obvious things to know are the maximum speed, acceleration and distance requirements of the sample move. Less obvious is the profile shape that is best to properly operate the load. The motor may be able to accelerate the load very quickly but doing so may also induce significant “ringing” in the motion profile. It might be better to reduce the acceleration and increase the velocity to minimize the ringing. Deciding the best profile for a given move is sometimes more “art” than hard calculation.

You will have to make a good first guess at the motion parameters to begin the tuning process. The tuning dialog includes a sampling oscilloscope that will allow you to execute a move and display a variety of measurements.

1) Entering a Sample Move

Enter move profile values in the “Sample Move” section. For this example, we will try a move distance of 8 revolutions. We need to choose speeds and acceleration rates that represent the actual application. For this exercise try 30rps and 200 rev/s/s.


2) Start with the KP & KD parameters

Before we try a move let's only start with the proportional (KP) & derivative (KD) gain parameters. Record the values of the other parameter settings and set them to zero. Do this by clicking the “Advanced” tab. The “Accel Feedforward” can only be set as low as “1”.

Simple	Advanced	Filters
Prop	16000	
Integral	0	
Deriv	5000	
Vel FB	0	
Vel FF	0	
Accel FF	1	

Starting with only these two terms is a good, safe way to begin. They are the minimum required in a servo system.

Note: If things go wrong (they usually do) there is a Servo OFF button on the bottom of the tuning window. Clicking it will disable the servo. Clicking Servo ON will enable the servo. Be ready to click Servo OFF if things go badly.



3) Let's Plot a Move

Start by selecting Actual Speed and Position Error for the Plot selections. Make sure the direction is set correctly, in some cases you may want to select alternate to avoid running the mechanism into a hard stop. For now select the “Sample Once” button.

Click the Start button and observe the results. It may not look very good as shown in the next figure.

Other problems may have occurred during the move depending on how things were set up. If a fault occurred you will have been asked to clear it, but the drive will be left disabled until the Servo ON button is clicked.

NOTE: Clicking the Servo OFF button, then the Servo ON button clears a fault and enables the drive.


4) Now we will adjust the motion parameters to get the desired move profile. You can repeat the move by clicking the Start button. If the drive continues to fault you may be exceeding current limit (see bottom of screen) or the position limit (Drive menu, top of screen).

To see what current is being required of the drive select Current in one of the Plot lists and click Start again to observe a move. This will show the current profile during the move and may give a clue as to why a fault is occurring.

After a successful move is accomplished you can begin to do a little tuning. Adjust the KP and KD parameters and observe the results. Be careful with the KD parameter: too little gain and the system will oscillate. Too much gain may cause the system to squeal from a high frequency oscillation.

In some cases where a very springy coupler is used between the motor and load, the KD parameter may need to be reduced until the system is stable.

At this point don't worry to much about the larger position error. We will take care of that later.



5) The return of KVf and KVff parameters


Now add back in the Velocity Feedback (KVf) and Velocity Feedforward (KVff) parameters that were zeroed in step 2. For large inertial loads these values can also be large.

The goal with these terms is to minimize the overshoot and get rid of the ringing when accelerating and decelerating. In the plot above, the red trace shows overshoot when the maximum speed is reached, and again when the motor reaches zero speed. There is no ringing in this plot, the system is almost damped enough.

We don't need to eliminate all the overshoot at this point because we have another term that will help.



Typically the KVf and KVff are kept the same. If we want to adjust all the damping values together at the same time use the damping slider on the Simple tab. This control keeps the damping values ratioed to each other when adjusting the gains.

Too much gain on the velocity parameters may cause an oscillation, usually apparent when running at the max speed or when stopped. Reduce the gain until the oscillation



tion is acceptable.

As a general guideline the velocity gain values are typically 2X the derivative gain value.



6) Adding in the KAff parameter

The acceleration feedforward (KAff) is a different kind of term from what we have just been working with. This term is used to deal with the inertia of a system. It will request more current during the acceleration and deceleration phases of the move profile.

Start by adding in 1/2 of the recorded value from the file.

In order to visually see the effect this will have on position error make sure the Autoscale check box at the bottom of the window is cleared. Now click the Start button and observe the results.

You should notice a reduction in position error (the peak values). The KAff term has a somewhat proportional affect on position error. If the error was reduced to half by setting KAff to 3500, then doubling it to 7000 should eliminate the rest of the error. If not you can estimate the next setting. Divide the previous error by the difference in error value then multiply this times the KAff value.


$$\text{KAff} = \text{previous error} / \text{delta error} * \text{KAff}$$

$$\text{KAff} = 220/90 * 3500$$


$$\text{New KAff} = 8555$$

Remember this is an estimation. If after doing this the position error goes negative during acceleration, we went too far. Adjust the value in smaller amounts to get as near zero error as possible. At any time you can click the Now button near the Auto Scale to zoom in on the new position error value.

You may have also noticed that the over-shoot at max speed and at the end of the move is now reduced. This is because the servo control is having to do less work to maintain good control.



KAff = 3500





KAff = 8555

7) Finishing off with the KI parameter


The final value to set is the integral gain (KI). The KI value works to minimize steady state position error. This is most often needed to insure very exact positioning when at the new position after the move. It can also help minimize position error during the move.

Again start with a small value and work up.

The KI value affects how fast the position error is acted on; larger values provide faster response times. As the value gets larger you may notice an oscillation in the position error. Adjust the KI value to give the best results without causing an oscillation in the system




KI = 4000




KI = 20000

8) Verify the Drive Current

This can be done at any time during the tuning process to make sure the current supplied to the motor is not being limited by the drive. You might also want to see how much current is being required and make changes to the move profile.



Acceleration = 200 rev/sec²



Acceleration = 600 rev/sec²